



Sonos


Sonos

User Guide

One SL

The speaker for stereo pairing and home theater surrounds.

- Compact design fits just about any space.
- Touch controls let you adjust volume, play and pause, or skip through songs.
- Pair with a Sonos One or another One SL for left-right stereo sound, or use a pair as rear surrounds for your home theater.
- Works with either  or .
- See **Getting started** when you're ready to add a Sonos One SL to your system.



Controls and lights

| | | |
|---------------------|-----------------------|--|
| ∴ | Volume control | <ul style="list-style-type: none"> • Touch and hold to quickly change the volume: • Volume up (right); Volume down (left). |
| > | Play/Pause | <ul style="list-style-type: none"> • Press <i>once</i> to play or pause music. • Press and hold to add the music that's playing in another room. |
| ∴ > ∴ | Next/Previous | <ul style="list-style-type: none"> • Swipe right across the touch controls to skip to the next song. • Swipe left to go to the previous song. <p>Note: You can't skip forward or go back when listening to a radio station.</p> |
| Status light | | Indicates the status. Learn more If the light is distracting, you can turn it off in your room's settings. |

Note: If you don't want anyone (like a child) to control playback or change the volume using the speaker touch controls, you can disable them in the room's settings.

Connector panel

| | |
|-------------------------------|---|
| Join button | Press to connect during setup. |
| Ethernet port | Use an Ethernet cable if you want to connect to a router, computer, or network-attached storage (NAS) device (optional). |
| AC power (mains) input | Use only the supplied power cord (using a third-party power cord will void your warranty). Note: Insert the power cord firmly until it is flush with the bottom of the speaker. |

Select a location

You can put your speaker just about anywhere. Here's a few guidelines:

- Sonos One SL sounds great even when placed next to a wall or on a shelf. For best performance, leave at least 1" (2.5 cm) space around the back of the speaker.
- It's *humidity*-resistant so you can use it in the bathroom.
- It's *not water*-resistant so don't put it near water or leave it in the rain.

Speaker mounts and stands

For wall mount kits or stands, tailored to perfectly fit your Sonos products, see [Accessories](#) on our website.

Specifications

| Feature | Description |
|-------------------------------|---|
| Audio | |
| Amplifier | Two Class-D digital amplifiers. |
| Tweeter | One tweeter creates a crisp and accurate high frequency response. |
| Mid-Woofer | One mid-woofer ensures the faithful playback of mid-range vocal frequencies plus deep, rich bass. |
| Stereo Pair | Turn two speakers into separate left and right channel speakers to create wider, deeper sound. |
| Home Theater | Add two speakers as surrounds for a true surround sound experience. |
| Networking* | |
| Wireless Connectivity | Connects to your home WiFi network with any 802.11b/g/n router. 802.11n only network configurations are not supported—you can either change the router settings to 802.11b/g/n or connect a Sonos product to your router. |
| Ethernet Port | One 10/100Mbps Ethernet port. You can plug a Sonos product directly into your router if your WiFi is unstable. |
| General | |
| Power Supply | Auto-switching 100 - 240V ~ 50-60 Hz 1A AC universal input |
| Dimensions (H x W x D) | 6.36 x 4.69 x 4.69 in. (161.45 x 119.7 X 119.7 mm) |
| Weight | 4.08 lb (1.85 kg) |
| Operating Temperature | 32° to 104° F (0° to 40° C) |
| Storage Temperature | -4° to 158° F (-20° to 70° C) |
| Humidity Resistant | Designed to withstand high-humidity, like in a bathroom with a running shower. (It is not waterproof or water-resistant.) |
| Product Finish | White with white grille; black with black grille |
| Package Contents | Sonos One SL, power cord, and Quickstart Guide. |

* Specifications subject to change without notice.

Important Safety Information

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry soft cloth. Household cleaners or solvents can damage the finish on your Sonos components.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
9. Protect the power cable from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Unplug this apparatus during lightning storms or when unused for long periods of time.
12. Refer all servicing to Sonos qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cable or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
13. The Mains plug should be readily available to disconnect the equipment.



14. **Warning:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

15. Do not expose apparatus to dripping or splashing and do not place objects filled with liquids, such as vases, on the apparatus.