DJI RS 4 Mini — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES														
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT
CANON	EOS M6 II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS M50	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS M50 II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS C50	✓	✓	✓	✗	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R5	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R5 Mark II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R6	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R6 Mark II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R6 Mark III	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R6 Mark V	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R7	✓	✓	✓	✓	✓	✓	✓	✗	✗	✗	✗	✗	✗	✗	✗
	EOS R8	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R50	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R50V	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS R100	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	EOS RP	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗
	PowerShot G7 X Mark III	✓	✓	✓	✓	✓	✓	✗	✗	✗	✓	✗	✓	✗	✓	✗
	PowerShot V1	✗	✓	✓	✓	✓	✓	✗	✗	✗	✓	✗	✓	✗	✓	✗
SONY	a7 II	✗	✗	✓	✗	✓	✗	✗	✗	✗	✓	✗	✓	✗	✓	✗
	a7 III	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7 IV	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7 V	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✗	✗	✓	✗
	a7C	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7C II	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7CR	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7R II	✗	✗	✓	✗	✓	✗	✗	✗	✗	✓	✗	✓	✗	✓	✗

DJI RS 4 Mini — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES														
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT
SONY	a7R III	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7R IV	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7R V	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a7S III	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a9	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a9 II	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a9 III	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a6100	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a6300	✗	✗	✓	✗	✓	✗	✗	✗	✗	✓	✗	✓	✗	✓	✗
	a6400	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a6500	✗	✗	✓	✗	✓	✗	✗	✗	✗	✓	✗	✓	✗	✓	✗
	a6600	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	a6700	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	FX3	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	FX30	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	RX100 VII	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	ZV-E1	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	ZV-E10	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
	ZV-E10 II	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗
PANASON	LUMIX G9	✓	✗	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✓	✗
	LUMIX G9 II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	LUMIX GH5	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	LUMIX GH5 II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	LUMIX GH5S	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	LUMIX GH6	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	LUMIX GH7	✓	✓	✓	✓	✓	✓	✓	✓	BT Only	✓	✓	✓	✓	✓	✓
	LUMIX S1 II	✓	✓	✓	✓	✓	✓	✗	✗	BT Only	✓	✓	✓	✓	✓	✓

DJI RS 4 Mini — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES														
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT
N I C	LUMIX S1 IIE	✓	✓	✓	✓	✓	✓	✗	✗	BT Only	✓	✓	✓	✓	✓	✓
	LUMIX S1R II	✓	✓	✓	✓	✓	✓	✓	✓	BT Only	✓	✓	✓	✓	✓	✓
	LUMIX S5	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	LUMIX S5 II	✓	✓	✓	✓	✓	✓	✓	✓	BT Only	✓	✓	✓	✓	✓	✓
	LUMIX S5 IIX	✓	✓	✓	✓	✓	✓	✓	✓	BT Only	✓	✓	✓	✓	✓	✓
N I K O N	Z5	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z5 II	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z6 II	✓	✓	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z6 III	✓	✓	✓	✓	✗	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z7	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z7 II	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z30	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z50	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Z50 II	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	Zf	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✗	✗	✗	✗
	Zfc	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✗	✗	✗	✗
	ZR	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
F U J I F I L M	X-H1	✓	✗	✗	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	X-H2	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	X-H2S	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
	X-M5	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓*	✗	✓	✗
	X-S10	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓*	✗	✓	✗
	X-S20	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓*	✗	✓	✗
	X-T2	✓	✗	✗	✗	✓	✗	✓	✗	✗	✓*	✗	✓*	✗	✓*	✗
	X-T3	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓*	✗	✓*	✗	✓*	✗
	X-T4	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓*	✗	✓	✗
	X-T5	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗

DJI RS 4 Mini — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES														
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT
	X-T30 II	✗	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✗	✗	✓	✗
SIGMA	fp	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✗	✗	✓	✗
OLYMPUS	E-M1 II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗
LEICA	Q3	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	SL3-S	✗	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗