DJI RS 4 — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES																	
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO		Ronin Image Transmitter	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT	Cable	BT
CANON	EOS 5D Mark III	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	EOS 5D Mark IV	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	EOS C50	✓	✓	✓	✗	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	EOD 6D	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	EOS 6D Mark II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS 7D Mark II	✓	✗	✓	✗	✓	✗	✗	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	EOS 70D	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	EOS 77D	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS 80D	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	EOS 90D	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS 200D II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✓
	EOS 800D	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS 850D	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS M6 II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS M50	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS M50 II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS R	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS R5	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS R5 Mark II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	EOS R6	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS R6 Mark II	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS R6 Mark III	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	EOS R6 V	✓	✓	✓	✓	✓	✗	✗	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	EOS R7	✓	✓	✓	✓	✓	✓	✓	✗	✗	✗	✗	✗	✗	✗	✗	✓	✓
CANON	EOS R8	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗

DJI RS 4 — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES																	
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO		Ronin Image Transmitter	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT	Cable	BT
CANON	EOS R10	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS R50	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	EOS R50V	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	EOS R100	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	EOS RP	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	PowerShot G7 X Mark III	✓	✓	✓	✓	✓	✓	✗	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	PowerShot V1	✗	✓	✓	✓	✓	✓	✗	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
SONY	a1	✓	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	✓	✓
	a7 II	Sony Multi Only	✗	✓	✗	✓	✗	✗	✗	Sony Multi Only	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✗
	a7 III	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a7 IV	✓	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	✓	✓
	a7 V	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✗	✗	✓	✗	✗	✗
	a7C	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✓	✓
	a7C II	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✓	✓
	a7CR	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✗	✓
	a7R II	Sony Multi Only	✗	✓	✗	✓	✗	✗	✗	Sony Multi Only	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✗
	a7R III	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a7R IV	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a7R V	✓	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	✓	✓
	a7S	Sony Multi Only	✗	Sony Multi Only	✗	Sony Multi Only	✗	✗	✗	Sony Multi Only	✗	✗	✗	✗	✗	✗	Sony Multi Only	✗
	a7S II	Sony Multi Only	✗	Sony Multi Only	✗	Sony Multi Only	✗	✗	✗	Sony Multi Only	✗	✗	✗	✗	✗	✗	Sony Multi Only	✗
	a7S III	✓	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	✓	✓
	a9	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi Only	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a9 II	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a9 III	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✗	✗

DJI RS 4 — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES																	
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO		Ronin Image Transmitter	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT	Cable	BT
SONY	a6000	Sony Multi Only	✗	✓	✗	✓	✗	✗	✗	Sony Multi Only	USB Only	✗	USB Only	✗	USB Only	✗	✓	✗
	a6100	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a6300	Sony Multi Only	✗	✓	✗	✓	✗	✗	✗	Sony Multi Only	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✗
	a6400	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a6500	Sony Multi Only	✗	✓	✗	✓	✗	✗	✗	Sony Multi Only	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✗
	a6600	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	a6700	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✓	✓
	FX3	✓	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi / BT	USB Only	✗	USB Only	✗	USB Only	✗	✓	✓
	FX30	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✗	✗
	RX100 VII	Sony Multi Only	✓	✓	✓	✓	✓	USB Only	✗	Sony Multi Only	USB Only	✗	USB Only	✗	USB Only	✗	Sony Multi Only	✓
	ZV-1 II	✗	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✗	✗
	ZV-E1	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✓	✓
	ZV-E10	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✗	✓
	ZV-E10 II	✓	✓	✓	✓	✓	✓	✓	✗	BT Only	✓	✗	✓	✗	✓	✗	✗	✗
PANASON	BGH1	✗	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	LUMIX G9	✓	✗	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✓	✗	✓	✗
	LUMIX G9 II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	LUMIX G95	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	LUMIX GH3	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	LUMIX GH4	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	LUMIX GH5	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	LUMIX GH5 II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	LUMIX GH5S	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	LUMIX GH6	✓	✗	✓	✗	✓	✗	USB Only	✗	✗	USB Only	✗	USB Only	✗	USB Only	✗	✓	✗
	LUMIX GH7	✓	✓	✓	✓	✓	✓	USB Only	✓	BT Only	USB Only	✓	USB Only	✓	USB Only	✓	✗	✗

DJI RS 4 — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES																	
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO		Ronin Image Transmitter	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT	Cable	BT
IC	LUMIX S1	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	LUMIX S1H	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	LUMIX S1 II	✓	✓	✓	✓	✓	✓	✗	✗	BT Only	✓	✓	✓	✓	✓	✓	✗	✗
	LUMIX S1 IIE	✓	✓	✓	✓	✓	✓	✗	✗	BT Only	✓	✓	✓	✓	✓	✓	✗	✗
	LUMIX S1R II	✓	✓	✓	✓	✓	✓	✓	✓	BT Only	✓	✓	✓	✓	✓	✓	✗	✗
	LUMIX S5	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	LUMIX S5 II	✓	✓	✓	✓	✓	✓	USB Only	✓	BT Only	USB Only	✓	USB Only	✓	USB Only	✓	✗	✗
	LUMIX S5 IIX	✓	✓	✓	✓	✓	✓	✓	✓	BT Only	✓	✓	✓	✓	✓	✓	✗	✗
NIKON	D500	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	D850	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	Z5	✓	✓	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	Z5 II	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	Z6	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	Z6 II	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✓
	Z6 III	✓	✓	✓	✓	✗	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	Z7	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	Z7 II	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	Z8	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✓	✗
	Z30	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	Z50	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	Z50 II	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	Zf	✓	✓	✓	✓	✓	✓	✓	✗	✗	✓	✗	✗	✗	✗	✗	✗	✗
	Zfc	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✗	✗	✗	✗	✗	✗
	ZR	✓	✓	✓	✓	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	X100V	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗

DJI RS 4 — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES																	
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO		Ronin Image Transmitter	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT	Cable	BT
FUJIFILM	X-E3	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	X-H1	RSS Only	✗	RSS Only	✗	RSS Only	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	X-H2	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	X-H2S	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
	X-M5	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓*	✗	✓	✗	✗	✗
	X-S10	✓	✗	✓	✗	✓	✗	USB Only	✗	✗	USB Only	✗	USB + Photo Mode Only	✗	USB Only	✗	✗	✗
	X-S20	✓	✗	✓	✗	✓	✗	USB Only	✗	✗	USB Only	✗	USB + Photo Mode Only	✗	USB Only	✗	✗	✗
	X-T2	✓	✗	RSS Only	✗	✓	✗	USB Only	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	X-T3	✓	✗	✓	✗	✓	✗	USB Only	✗	✗	USB + Photo Mode Only	✗	USB + Photo Mode Only	✗	USB + Photo Mode Only	✗	✗	✗
	X-T4	✓	✗	✓	✗	✓	✗	USB Only	✗	✗	USB Only	✗	USB + Photo Mode Only	✗	USB Only	✗	✗	✗
	X-T5	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	X-T20	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	X-T30	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	X-T30 II	RSS Only	✗	✓	✗	✓	✗	USB Only	✗	✗	USB Only	✗	✗	✗	USB Only	✗	✗	✗
SIGMA	fp	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✗	✗	✓	✗	✓	✗
OLYMPUS	E-M1 II	✓	✗	✓	✗	✓	✗	✓	✗	✗	✓	✗	✓	✗	✓	✗	✗	✗
ZCAM	E2	✓	✗	✓	✗	✓	✗	✗	✗	✗	✓	✗	✗	✗	✓	✗	✓	✗
	E2-F6	✓	✗	✓	✗	✓	✗	✗	✗	✗	✓	✗	✗	✗	✓	✗	✓	✗

DJI RS 4 — Camera Compatibility Chart

Last Updated: 10/18/2026

✓ = Supported ✓ = Supported in Photo Mode Only ✗ = Not Supported Cable = Multi-Camera Control Cable BT = Bluetooth Empty Cells = Not Yet Yested by DJI*

CAMERA		CONTROL FEATURES																	
Brand	Model	Capture Photo		Start/Stop Rec. Video		Trigger Auto Focus		Pull Focus Electronically		Zoom Control	Aperture		Shutter		ISO		Ronin Image Transmitter	
		Cable	BT	Cable	BT	Cable	BT	Cable	BT		Cable	BT	Cable	BT	Cable	BT	Cable	BT
LEICA	Q3	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	SL2	✗	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	SL2-S	✓	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	SL3-S	✗	✗	✓	✗	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗