




LITE THE NITE
TECHNOLOGIES LLC

LiteTouch and LiteTouch PRO Wall Mount



Landscape VESA Max 800*600
Portrait VESA Max 400*600



LiteMountA

Thank you for choosing the Lite Touch™ and Lite Touch Pro™ wall mount for your display panel installation.





The mount can be configured in landscape or portrait orientation.



To install your panel in landscape orientation, complete steps 1 thru 8 of this manual.

To install your panel in portrait orientation, complete steps 10 thru 15.

Installation Overview

1. Assemble the wall bracket for a landscape or portrait installation
2. Mount the wall bracket at the desired mounting location
3. Attach the panel brackets to the display panel
4. Lift the panel onto the top rail of the wall bracket
5. Snap the bottom of the panel onto the wall bracket
6. Level the display panel using the lateral adjustment screws


Panel Bracket  2PCS	Left Wall Mount Bracket  1PCS	Center Wall Mount Bracket  1PCS	Right wall Mount Bracket  1PCS
--	--	--	--

A  M5X15 4PCS M6X15 4PCS M8X15 4PCS M10X15 4PCS	B  10X70 8PCS	C  12X70 8PCS	D  M5 4PCS M6 4PCS M8 4PCS M10 12PCS
E  8mm 1PCS 6mm 1PCS 5mm 1PCS 4mm 1PCS	F  17mm 1PCS 14mm 1PCS	G  15X8X15 4PCS	

1

Landscape Installation

Below is an example of the assembled wall mount bracket configured for a landscape installation




VESA MAX 800X600

2

Assemble The Wall Mount Bracket

Attach the center wall mount bracket to the left wall mount bracket and right wall mount bracket using washers (D) and nuts as shown





3

Solid Brick and Concrete Block Landscape Mounting

- A. Drill a 15/32" hole 2 3/4" deep at each of the mounting locations and insert the plastic anchors (C)
- B. Attach the wall mount bracket to the wall using screws (B) and washers (D)

NOTE:


Attach the wall mount bracket using at least 8 screws



4

Wood Wall Stud Landscape Mounting

- A. Locate the wood studs in the wall and mark the stud centers. Be sure to attach wall mount to at least 2 studs
- B. Drill a 3/16" pilot hole at each of the mounting locations in the center of the stud
- C. Attach the wall mount bracket to the wall using screws(B) and washers(D)







5

Attach The Panel Brackets To The Display Panel

A. Install the panel brackets to the rear of the display panel with the “hook” up as shown below using screws (A) and washers(D). Tighten screws (A) with allen wrench(E)


NOTE:

Install spacers(G) if your display panel has a recessed back. Be sure the mount is attached as shown



6

Attach The Display To The Wall Mount



NOTE:

This step should be completed with 2 people due to the weight of the display panel

- Lift the display panel above the wall mount and lower the panel bracket hooks onto the top of the wall mount
- Push the bottom of the display toward the wall mount until it “snaps” into place
- If the quick release strings are hanging beneath the display panel, place the magnetic knobs on the mount to keep the strings out of sight


7

Level The Display Panel

Level the display panel using a long phillips screwdriver to turn the lateral adjustment screws in the top of panel brackets as shown below

Tip:


Raise the low side of the display panel first



8

Adjust Display Panel Tilt


Adjust the display panel tilt from -5 degrees to +10 degrees as desired. Grasp the display panel at the top and bottom and move it to the desired angle. Tighten or loosen the Tilt Adjustment Knobs as needed.



Congratulations! Your wall mount installation is complete

9

How To Remove The Display panel From The Wall Mount Bracket



NOTE:


This should be completed with 2 people due to the weight of the display panel

- Pull down on both display panel quick release cables simultaneously while pulling the bottom of the display panel away from the mounting bracket
- Pickup the display panel until it is free from the wall mount

10

Portrait Installation

Below is an example of the assembled wallmount bracket configured for a portrait installation using the left wall mount bracket






VESA MAX 400X600

11

Solid Brick and Concrete Block Portrait Mounting

- A. Drill a 15/32" hole 2 3/4" deep at each of the mounting locations and insert the plastic anchors(C)
- B. Attach the wall mount bracket to the wall using screws(B) and washers(D)








- A. Locate the wood studs in the wall and mark the stud centers. Be sure to attach wall mount to at least 2 studs
- B. Drill a 3/16" pilot hole at each of the mounting locations in the center of the stud
- C. Attach the wall mount bracket to the wall using screws(B) and washers(D)

13


A. Install the panel brackets to the rear of the display panel with the "hook" up as shown below using screws(A), washers(D) and allen wrench(E)

B. Install spacers (G) if your display panel has a recessed back

Be sure the mount is attached as shown



14 Attach The Display To The Wall Mount




NOTE:

This step should be completed with 2 people due to the weight of the display panel

- A. Lift the display panel above the wall mount and lower the panel bracket hooks onto the top of the wall mount
- B. Push the bottom of the display toward the wall mount until it “snaps” into place
- C. If the quick release strings are hanging beneath the display panel, place the magnetic knobs on the mount to keep the strings out of sight

15 Level The Display Panel



Level the display panel using a long phillips screwdriver to turn the lateral adjustment screws in the top of panel brackets as shown below

Tip:

Raise the low side of the display panel first

Congratulations! Your wall mount installation is complete