



H756 OnWall Mount for iPad 10th Generation



In the box

Mount the pocket to your wall

Determine the height of your installation

Review the hole and slot patterns on the pocket

Hold the enclosure to the drywall at the desired installation height

Remove the tablet enclosure from the pocket

Option 1: Mount directly to drywall

Option 2: Mount to a US gang box

Option 3: Mount to a European wall box

Install the iPad 10th Generation

Loosen the top, bottom, and side enclosure brackets

Position the iPad into the enclosure

Tighten the enclosure-bracket screws

Install your PoE adapter inside the pocket


Install the tablet enclosure to the pocket

Connect charging cable to PoE(optional)

Hang the enclosure on the pocket

Tighten the set screws

In the box




- a. 1 x OnWall mount
- b. 2 x Drywall anchors (F155)
- c. 2 x Drywall anchor screws (F360)
- d. 1 x Set Screw Assembly Key (F914)
- e. 1 x Enclosure Assembly Key (F529)
- f. 1 x Velcro dot set
- g. 1 x Cable Tie (F817)

Mount the pocket to your wall

 Use the fully assembled OnWall Mount as your hole template.

Determine the height of your installation


 To install your iPad to your Drywall at an ADA-compliant height, position the enclosure so that the top edge of the iPad screen is no higher than 48 inches above the finished floor.





Review the hole and slot patterns on the pocket


Hold the enclosure to the drywall at the desired installation height

Mark the two screw positions and the CAT cable hole position as shown.



Remove the tablet enclosure from the pocket






Option 1: Mount directly to drywall

Install drywall anchors.


 For safety, shut off electricity in the installation area before drilling holes or installing hardware into your walls.

 For your convenience, two drywall-mounting anchors and screws are provided. If you feel this hardware is not appropriate for use with your wall, please source alternate hardware.





Drill the hole for CAT cable.

💡 Route your CAT cable through the wall and out through this hole.




Mount the pocket on the drywall.






Option 2: Mount to a US gang box

💡 Route your CAT cable through the wall and out through the gang box.





Option 3: Mount to a European wall box

💡 Route your CAT cable through the wall and out through this wall box.



Install the iPad 10th Generation



Loosen the top, bottom, and side enclosure brackets





Position the iPad into the enclosure

💡 Connect the right-angle USB-C adapter & Apple USB-C cable.

- 💡 Position the iPad carefully so it does not drop into the screen-cut-out window of the stand.




Tighten the enclosure-bracket screws



Install your PoE adapter inside the pocket

💡 Connect your CAT cable to your PoE adapter.



Install the tablet enclosure to the pocket

Connect charging cable to PoE(optional)

