




Premium Heavy Duty Floorstand with Security Holder for uniVERSE Series Cases

OTT-PARAF

INSTRUCTION - MANUAL

CONTENTS:




INSTALLATION:


1. Attaching Floorstand Base to Body

1A. First, take the two halves of the base (K) and combine as illustrated to the right. Then, take the body of the floor stand (K) and align the mounting holes at the bottom to the holes of the combined base plates.

Rotate in screws (B) from above through both mounting holes using provided tool (H) until securely fastened.



2.Attaching Security Holder to Floorstand




2A. Align the VESA holes of the back of the security holder (J) to the VESA holes on the front of the floor stand as illustrated.


Find and identify the open slots on the back side of the floorstand (K).

Take the screw (E) and rotate through the open slots on the back of the holder using provided tool (G) until securely fastened. Repeat for all the holes.

3.Inserting Tablet into Security Holder



3A. First, make sure the holder is in unlocked position. Insert key (F) to unlock as needed. Using your hands, extend the holder in the Y-direction.



3B. Locate the Z-direction grip arms. On the inside for both the top and bottom, there is a circular button. Press down to loosen the grip arms and extend outwards.



** Tablet and case not included. Shown for example purposes only.

3C. Insert a tablet with compatible case attached. Make sure the two adapters are aligned. Once you insert the tablet with case, it will slide down to let you know it is in the right location.



3D. Re-insert the tablet with compatible case. Using your arms, retract the holder in the Y-direction and Z direction until securely fitted.