impact®



FF-OSB60 Octa Softbox 24″

INSTRUCTIONS

Precautions ⚠


- Please read and follow these instructions and keep this manual in a safe place.
- Keep this product away from water and any flammable gases or liquids.
- Use only lights with the recommended wattage.
- Handle this unit with care.
- Keep this unit away from children.
- Use only parts provided by the manufacturer.
- Make sure that this product is intact and that there are no missing parts.
- All photos are for illustrative purposes only.

Specifications	FF-OSB60
Dimensions	Diameter: 24˝ (60 cm), Depth: 14˝ (35.6 cm)
Weight	0.8 lb. (0.36 kg)
Shape	Octagonal
Compatibility	Impact FF-OF4 Octa 4-Socket Fluorescent Fixture
Removable front face	Yes
Removable interior baffle	None
Accepts grids	No
Requires speed ring	No

Introduction

Thank you for choosing the Impact FF-OSB60 Octa Softbox 24˝. This softbox is designed to be used with the FF-OF4 Fluorescent 4-socket fixture. The Octa Softbox 24" includes a front diffuser that is attached with touch-connect strips on all edges, and is ideal for situations where softening the light is desired. This softbox is for use with fluorescent lights only. It should not be used with incandescent or tungsten lights.

Overview




1. Octa Softbox 24 diffuser
2. Flex rods (8)
3. Front diffuser
4. Carry bag

Assembling the Octa Softbox 24 with the FF-OF4 Fluorescent 4-socket fixture

Note: light stands, light fixtures, and bulbs are not included with this softbox unless purchased as a kit.






1. Before assembling the FF-OSB60 Octa Softbox, unplug the FF-OF4 and remove all fluorescent lamps.
2. Unfold the softbox and run the power cord of the FF-OF4 through the center of the softbox from the inside out.

Position the retracted FF-OF4 inside the softbox and first move the locking knob and receiver assembly through the elastic ring. Then fit the elastic ring of the softbox around the base of the fixture. Make sure that the flex rod sockets are accessible from the inside of the softbox.


Assembly Instructions





3. Insert the plain end of first flex rod in any of the eight flex rod sockets on the fixture head. Adjust the softbox so that the flex rod is aligned with one of the pockets on the outer edge of the softbox. Insert the stud end of the flex rod into the pocket by bending it so that it can be inserted into the pocket.
4. Attach the next rod directly opposite to where the first rod was inserted. Insert the plain end into the flex rod socket first, and then insert the stud (silver) end into the pocket on the softbox.
5. Attach the next two rods at a 90° angle from the first two rods that were inserted. Follow the same steps as with the first two flex rods: insert the plain end into the flex rod socket, and firmly bend the flex rod so that it can be inserted into the pocket on the softbox.

Assembly Instructions





6. Attach the remaining rods, always placing one flex rod, and then the next on the opposite side. Once all the flex rods are in place the fabric of the Octa Softbox should be stretched tight and the softbox should keep its shape.
7. Screw in all the fluorescent bulbs. Only touch the base of the bulb; never touch the glass itself.
8. Stretch the diffuser around the opening of the softbox. Press down on the touch fasteners to seal it.
9. At this point you can mount the light fixture and softbox assembly on to a light stand. Use a sandbag or other weight to stabilize the assembly.

Disassembly Instructions

1. Turn off the power to your light fixture and disconnect the power cord from the power supply.
2. Remove the diffuser from the softbox.
3. After the bulbs have cooled off, remove them from the fixture.
4. Unmount the fixture from the light stand.
5. Bend one of the flex rods to release it from the pocket and then from the flex rod socket. You will have to firmly bend the flex rod to release it.
6. The next flex rod to remove should be the one directly opposite the first one removed.
7. Remove the remaining flex rods.
8. Return all softbox items to the carry bag.

Recommended Accessories



Impact FF-OF4 Octa 4 Socket Fluorescent Fixture

The Impact FF-OF4 is a compact and portable lighting fixture that uses four CFL bulbs up to 105W per socket. The FF-OF4 mounts on any 5/8" stud, and two light switches provide control over your light source. The built-in umbrella socket and locking tilt knob provide even more lighting options. And with the multi-voltage circuitry (100~240V/50/60 Hz) you can plug in the FF-OF4 anywhere.



Impact LS-8A Light Stand

The Impact LS-8A Light Stand is one of the most economical light stands available. It extends to a maximum height of 8' and has a standard 5/8" stud on top with a ¼"-20 thread.

Other Accessories

- Impact Swivel Umbrella Adapter (CA-108)
- Impact Super Clamp with T-Handle (CC-106T)
- Impact 3 Section Double Articulated Arm without Bracket (BHE-119)
- Impact Combo Boom Stand – 12.95' (LS-CB6)
- Impact Double Ball Joint Head (CC-131)
- Impact Holder for Collapsible Reflectors (ME-109)

One-Year Limited Warranty

This Impact product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Impact Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Impact along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.impactstudiolighting.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

Impact is a registered trademark of the Gradus Group.
© 2020 Gradus Group LLC. All Rights Reserved.

IMPACT®
A Gradus Group Brand