材质：105G铜板纸，双面四色印刷

成型尺寸：62x120mm,

正面

GlocalMe

U3 User Manual

uCloudlink

Copyright © 2021 uCloudlink All Rights Reserved

Product Overview



1. Wi-Fi LED Indicator
2. Battery LED Indicator
3. Signal LED Indicator
4. Strength LED Indicator
5. Handle position for opening front panel
6. Power button
7. Reset button
8. Type-C(Input)

Function Introduction

1. Power on: Press power button for 3 seconds.
2. Power off : Press power button for 5 seconds.
3. Reset: Press power button for 14 seconds.
4. Restore Factory Settings: Press reset button for 5 seconds.
5. Battery Capacity and Signal Strength: Press the power button, the battery capacity will be shown in the first 3 seconds, then the signal strength will be shown afterwards.

LED Indicator Type	Status	Remarks
Wi-Fi LED Indicator	On	Ready for internet connection
	Off	No internet connection
	Flashing	Service connecting
Signal LED Indicator	On	The signal strength is shown by strength LED indicator
	Flashing	Service Error
Battery LED Indicator	On	The battery capacity is shown by strength LED indicator
	Flashing	Charging

Local SIM

1. Local SIM is supported by U3. Only insert Nano-SIM card (small card). Please turn off the device first if you want to insert/pull out the SIM card.
2. Use a needle to pull out the SIM cards as shown in the picture below. Please contact customer service if any issue encountered

※U3 device does not support SIM cards with PIN code. If you want to use this type of SIM cards, please unlock the PIN code first.

Function Introduction

Brand: GlocalMe Model No.: GLMU19A02
Box content: Device, User Manual, Type-C cable, SIM removal tool

Technical Specification:

- Size: 126*66*10mm
- LTE FDD: B1/2/3/4/5/7/8/9/12/13/17/18/19/20/25/26/28/66
- LTE TDD: B34/38/39/40/41(194M)
- WCDMA: B1/2/4/5/6/8/9/19
- GSM: 850/900/1800/1900
- Max Upload Speed: 50Mbps
- Max Download Speed: 150Mbps
- Wi-Fi: IEEE802. 11b/g/n
- **Wi-Fi Frequency: 2.4GHz**
- USB port: Type-C (Input)
- Battery Capacity: 3000mAh
- Power Input: DC 5V⎓2A

Quick Start Guide

1. Register an Account: Scan the QR code below to download the GlocalMe App. You can register for an account after installation.

2. Activate Device: Use the GlocalMe app to scan the QR code on the back panel of the device.

IMEI:123456789012345
SSID: admin
PWD: admin

3. Purchase Package: Purchase package or top up through the GlocalMe app.

4. Power On: Press power button for 3 seconds.

5. Connect to GlocalMe: When the When the Wi-Fi LED indicator " " is staying on, turn on Wi-Fi on your cell phone, select GlocalMe Wi-Fi, enter the password to connect to the internet. (Wi-Fi name and password can be seen on the back panel, as shown below)

6. Device Management: Enter "192.168.43.1" in the address bar of web browser, and enter the username and password to login. (The initial username and password are admin/admin).

Warning

Specific Absorption Rate (SAR) information. SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new device can be made available for sale to the public, it must be tested and certified by the FCC that it does not exceed the exposure limit established by the FCC.Tests for each device are performed in positions and locations as required by the FCC. For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the device a minimum of 1.0 cm from the body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause.

Undesired operation.Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and complies with the limits for a Class B digital device, pursuantto part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur during installation. If the device does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is suggested to try to correct the interference by the following measures:

--Reorient or relocate the receiving antenna.
--Increase the distsnce between the equipment and receiver
--Connect the equipment to an outlet on different circuit to the receiver
--Consult the manufacturer or an experienced radio/TV technician for help.

Information on the disposal and recycling of the devices. This symbol (with or without a solid bar) on the device, batteries (if included), and/or the packaging, indicates that the device and its electrical accessories (for example, a headset,adapter,or cable) and batteries should not be disposed of as household garbage. These items should not be disposed of as unsorted municipal wasted and should be taken to a certified collection point for recycling or proper disposal. For detailed information about device or battery recycling, contact your local city office, housedhold waste disposal service, or retail store.
Disposal of the device and batteries (if included) is subject to WEEE. Directive Recast (Directive 2012/19/EU) and Battery Dirctive (Directive 2006/66/ec). The purpose of separating WEEE and batteries from other waste is to minimize the potential environmental impacts and human health risk of any hazardous subsatances that may be present.

Contact Us

facebook.com/GlocalMe

GlocalMe WeChat platform

Hong Kong uCloudlink Network Technology Limited

E-mail: service@ucloudlink.com

Hotline: +852 8191 2660 or +86 400 699 1314（China）

Facebook: GlocalMe

Instagram: @GlocalMeMoments

Twitter: @GlocalMeMoments

YouTube: GlocalMe

Address: SUITE 603, 6/F, LAWS COMMERCIAL PLAZA, 788 CHEUNG SHA WAN ROAD, KOWLOON, HONG KONG

uCloudlink

This product and related system are protected by one or more of uCloudlink's patents, details please refer to https://www.ucloudlink.com/patents

Copyright © 2021 uCloudlink All Rights Reserved

V2.0

反面

GlocalMe

U3 用户手册

uCloudlink

Copyright © 2021 uCloudlink All Rights Reserved

产品介绍



1. WIFI联网指示灯
2. 电量指示灯
3. 信号指示灯
4. 强度指示灯
5. 插卡位置
6. 电源键
7. 恢复出厂设置
8. Type-C接口

功能说明

1. 开机：长按电源键3秒开机。
2. 关机：长按电源键5秒关机。
3. 重启：长按电源键14秒重启。
4. 恢复出厂设置：长按恢复出厂设置按键5秒。
5. 电量和信号显示：短按电源键，先显示电量强度3秒，再显示信号强度3秒。

指示灯类型	状 态	说 明
WIF联网指示灯	长亮	可以上网
	灭	不可以上网，等待灯亮
	闪烁	正在联网中
信号指示灯	亮	强度指示灯（4）显示的为信号强度
	闪烁	联网异常
电量指示灯	亮	强度指示灯（4）显示的为电池电量
	持续闪烁	充电中

插卡说明

1. U3支持插入实体SIM卡，使用实体SIM卡上网。只能插入Nano-SIM卡（小卡），如果是标准的SIM大卡或Micro-SIM(中卡)则需要剪卡。插SIM卡或拔SIM卡时需将设备关机，切勿开机时插拔SIM卡。
2. 拔卡时请用取卡针将卡槽顶出，根据图示方向放入SIM卡，若使用过程中出现异常可联系售后客服处理。
3. 设备不支持带PIN码的SIM卡，如需使用此类SIM卡，请先解除PIN码。

产品简介

品牌:GlocalMe 型号: GLMU19A02
产品清单:整机1 台，说明书1 本，数据线1 条，卡针1个

技术参数：

- 尺寸：126*66*10mm
- LTE FDD：B1/2/3/4/5/7/8/9/12/13/17/18/19/20/25/26/28/66
- LTE TDD：B34/38/39/40/41(194M)
- WCDMA：B1/2/4/5/6/8/9/19
- GSM：850/900/1800/1900
- Max Upload Speed: 50Mbps
- Max Download Speed: 150Mbps
- WiFi协议：IEEE802.11b/g/n
- WiFi频率：2.4GHz
- 接口：Type-C接口
- 电量：3000mAh
- 输入：DC 5V⎓2A

操作流程

1、账号注册:扫描右边二维码下载GlocalMe APP，安装完成后，注册账号并登录；
2、设备绑定：使用APP扫描设备背面的二维码绑定设备；
3、购买套餐：在GlocalMe APP里选择购买合适的套餐或直接充值到余额；
4、设备开机：长按开机键3秒开机；
5、连接设备：待设备WIFI指示灯常亮后，打开手机WIFI设置，选择GlocalMe WIFI连接（WIFI账号和密码详见设备背面，如右图所示）
6、设备管理：连接上设备WIFI后，在手机浏览器地址栏输入"192.168.43.1"，输入账号密码即可进入管理页面（初始账号和密码为admin/admin）

IMEI:123456789012345
SSID: admin
PWD: admin

注意事项

手册中或包装上设备的功能描述以及图片仅供参考，您的设备可能与此不同，请以实物为准。

本手册描述的产品及其附件的某些特性和功能，取决于当地网络的设计和性能，以及您安装的软件。某些特性和功能可能由于当地网络运营商或网络服务供应商不支持，或者由于当地网络的设置，或者您安装的软件不支持而无法实现。因此，本手册中的描述可能与您购买的产品或其附件并非完全一一对应。

深圳市优克联新技术有限公司保留随时修改本手册中任何信息的权利。无需进行任何提前通知。

在使用和操作本设备前，请阅读并遵守下面的注意事项，以免出现危险或非法情况，并确保本设备性能最佳。

进出口管制

若需将此产品手册描述的产品（包含但不限于产品中的软件及技术数据等）出口、再出口或者进口，您应遵守适用的进出口管制法律法规。

操作环境

请勿在多灰、潮湿、肮脏或靠近磁场的地方进行充电或使用本设备，以免引起设备内部电路故障。雷雨天气时，请勿使用设备，以免受到雷击或其它伤害。有明文规定禁止使用无线设备的场所，请关闭本设备。建议在环境温度为 0°C～+35°C的情况下使用，请勿在温度过高或过低的环境中使用本设备。请将设备或其配件放置在通风、阴凉、无阳光直射的地方，请勿将设备包裹密封或在设备上覆盖毛巾及放置其它物品，请勿将设备放置在盒子或箱子中使用，以免散热不良导致设备损坏。

儿童健康

本设备及其配件可能包含一些小零件，请将其放置在儿童接触不到的地方。儿童可能无意损坏本设备及其配件，或吞下小零件导致窒息或其他危险。

交通安全

驾车时请勿持握本设备，并遵守所在地区或国家的相关规定。请勿将设备放在汽车安全气囊上方或安全气囊展开后能够触及的区域内。否则当安全气囊膨胀时，设备就会受到很强的外力推动而对车内人员造成严重伤害。无线设备可能干扰飞机的飞行系统，请遵守航空公司的相关规定，在禁止使用无线设备的地方，请关闭该设备。

环境保护

在明文规定禁止使用无线设备的医疗和保健场所，请遵守该场所的规定，并关闭本设备。本设备产生的无线电波可能会影响植入式医疗设备或个人医用设备的正常工作，如起搏器、植入耳蜗、助听器等。若您使用了这些医用设备，请向其制造商咨询使用本设备的限制条件。

医疗设备

请遵守有关设备、电池及其配件处理的本地法令，并支持回收行动。请勿将设备、电池及其配件作为普通的生活垃圾处理。

无承担说明

本手册中的内容均"如是"提供，除非适用法要求，深圳市优克联新技术有限公司对本手册中的所有内容不提供任何明示或暗示的保证，包括但不限于适销性或者适用于某一特定目的的保证。

在法律允许的范围内，深圳市优克联新技术有限公司在任何情况下，都不对因使用本手册相关内容而产生的任何特殊的、附带的、间接的及做发性的损害进行赔偿，也不对任何利润、数据、商誉或预期节约的损失进行赔偿。因软件版本的不断更新，设备的操作界面会与说明书有细微差异，具体请以实际体验为准。

电磁辐射比吸收率（SAR）

本产品电磁辐射比吸收率（SAR)最大值小于2.0W/kg,符合国家标准 GB21288-2007的要求。

易燃易爆区域

在加油站或靠近易燃物品、化学制剂的地方，请勿使用本设备，并遵守所有图形或文字的指示。在燃油或化学制剂存放和运输区或易爆场所内及周围，设备可能引起爆炸或起火。请勿将设备及其配件与易燃液体、气体或易爆物品放在同一箱子中存放或运输。

维护和保养

请保持设备及其配件干燥。请勿使用微波炉等外部加热设备对其进行干燥处理。请勿使设备及其配件受到强烈的冲击或震动，以免损坏设备及其配件，或者导致电池燃烧或爆炸。

请不要使用烈性化学制品、清洗剂或强洗涤剂清洁设备或其配件。清洁和维护前请先关机，并断开充电器与设备的连接。请勿擅自拆卸设备及配件，否则该设备及配件将不在本公司保修范围之内。

使用电池和充电器

用户必须选用3C强制性认证的合格充电器（输出为5V 2A的充电器）当充电完毕或者不充电时，请断开与设备的连接并从电源插座上拔掉充电器。请勿将电池或设备放置在加热设备的周围，如微波炉、烤箱或散热器等。电池过热可能引起爆炸。请勿拆解或改装电池，以免引起电池漏液、过热、起火或爆裂。如果电池漏液，请不要使皮肤或眼睛接触到漏出的液体；若沾到皮肤或眼睛上，请立即用清水冲洗，并到医院进行医疗处理。如果电池在使用、充电或保存过程中有异常发热等异常现象，请停止使用。若充电器电源线已经损坏，请勿继续使用，以免发生触电或火灾。请勿把设备扔到火里，否则会导致电池起火和爆裂。用错误型号电池更换会有爆炸危险，务必按照说明处置用完的电池。

产品中有毒有害物质或元素的名称及元素

产品中有毒有害物质或元素的名称及元素

部件名称		有毒有害物质或元素					
		铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
接线设备	印刷电路板组件*	X	X	X	X	X	X
	上壳组件	X	X	X	X	X	X
	中壳组件	X	X	X	X	X	X
	下壳组件	X	X	X	X	X	X
	支架	X	X	X	X	X	X
	天线	X	X	X	X	X	X
	电池电芯	X	X	X	X	X	X
	USB充电线	X	X	X	X	X	X

该操作系统仅支持官方提供的系统更新,若用户刷第三方的ROM系统或采用任何破解的方式修改系统软件,可能会导致系统不稳定,可能会带来安全风险或危险,用户需要为类似行为承担责任。

此产品以及相关系统受优克联专利技术保护，详情请查阅
https://www.ucloudlink.com/patents

客服联系方式

GlocalMe官方微信平台

深圳市优克联新技术有限公司
官网:www.glocalme.com
客服热线：+852-8191-2660/+86 400-699-1314
（数字键1转售前服务，数字键3转售后服务）
邮件:技术与售后问题，邮件联系我们 service@ucloudlink.com
地址:中国深圳市南山区学府路软件产业基地1栋A座3层

V2.0