

PDC9-BRS
Portable Dry Case
9.6 L

[®]
Ruggard



THANK YOU FOR CHOOSING RUGGARD.

The Ruggard Portable Dry Case protects your lenses, photographic and optical equipment, mobile electronics, and other valuables from excessive moisture. Using the included rechargeable dehumidifier, you can reduce the interior relative humidity to help prevent fungus and corrosion from damaging your gear. The case offers silent operation with no fan or compressor, and the unit is dripless, so there's no need for a water tray. Grab the case and bring it with you to your next location shoot, and keep your equipment sealed and protected against moisture-rich climates.

PRECAUTIONS

- Please read and follow these instructions, and keep this manual in a safe place.
- Keep this product away from children under 3 years old, as the small parts can pose a choking hazard.
- Keep this product away from direct sunlight and high-temperature heat sources.
- Do not cover the vents.
- Do not attempt to disassemble the unit.
- Do not drop or expose the dehumidifier to strong shocks.
- All images are for illustrative purposes only.

SPECIFICATIONS

PDC9-BRS

Dimensions (H × W × D)	Inner: 8 × 10.1 × 7.5 in. (20.3 × 25.7 × 19 cm) Outer: 8.4 × 11.4 × 9.25 in. (22.9 × 29 × 23.5 cm)
Volume	0.34 cu. ft. (9.6 L)
Weight	Case: 2.8 lb. (1.3 kg) Case with dehumidifier: 3.6 lb. (1.6 kg) Case, dehumidifier, and fabric insert: 3.86 lb. (1.75 kg)

Dehumidifier

Input voltage	110 to 220 V, 50/60 Hz
Relative humidity	50% to 25%
Input voltage	12 V / 2 A DC
Charging time	4-6 hr.
AC Adapter	12 V / 2 A
Dimensions (H × W × D)	3.2 × 6.5 × 1.6 in. (8.1 × 16.4 × 4 cm)
Weight	12.1 oz. (344 g)

Optimal Relative Humidity (RH) Levels

(RH) Level	Recommended Items
40%-50%	Camcorders, cameras, lenses, telescopes, microscopes, endoscopes, compact discs, film negatives, film transparency/slides, microfilm, disk drives, audio tape

OVERVIEW

PDC9-BRS

1. Handle

2. Hygrometer: Displays relative humidity level.

3. Rubber gasket

4. Latch

5. Security lock slot

6. Shoulder strap mount

Also included

- Foam liner
- Fabric insert
- Padded dividers (×2)
- Shoulder strap: Adjustable from 35 to 58 in.
(89 to 147.3 cm)



OVERVIEW

Dehumidifier

1. Gel status window: View the current moisture saturation level of the gels. Orange is low saturation, and green is high saturation. After completely charging the gels, let the dehumidifier cool for 10 to 20 minutes before use. Then, place it inside the Portable Dry Case along with the equipment you want to keep dry.

2. Air vents


3. Power LED: Shows that the dehumidifier is receiving power. Charging can last up to 12 hours or until the gels turn orange.

Warning! When the dehumidifier is plugged into an outlet for charging, the unit can become hot to the touch.

4. DC socket

Also included

- AC adapter



NINETY-DAY LIMITED WARRANTY

This Ruggard product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of ninety (90) days from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Ruggard Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Ruggard along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.ruggard.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.
www.gradusgroup.com

Ruggard is a registered trademark of the Gradus Group.
© 2021 Gradus Group LLC. All Rights Reserved.

