




MOUNT-IT!

Premium AV & Office Products

MI-2752L

INSTALLATION MANUAL

Dual Monitor Desk Mount



UNPACKING INSTRUCTIONS


- Carefully open the carton, remove contents and lay out on cardboard or other protective surface to avoid damage.
- Check package contents against the Supplied Parts List in the next page to assure that all components were received undamaged. Do not use damaged or defective parts.
- Carefully read all instructions before attempting installation.

IMPORTANT SAFETY INFORMATION


- Install and operate this device with care. Please read this instruction before installation, and carefully follow all instructions contained herein. Use proper safety equipment during installation.
- Please call a qualified installation contractor for help if you don't understand these directions or have any doubts about the safety of the installation.

Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaims any and all liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.


Supplied Parts List




(1) Pole-a



(1) Clamp-b



(1) Clamp Brace-c



(1) Swivel Arm-d



(2) VESA Plate-e



(2)M8X12 Bolt-f



(1)M10 Bolt-h



(1)Support Plate-i



(1)M10 Washer-j



(1)Spring Washer-k



(1)Grommet Base
Plate-l



(1)Wire Clip-m



(4)wire Clip-n



(1) Allen Key -o



(1) Wrench-p



(8) M4X12 Bolt -q



(8) M4X30 Bolt -r



(8) M8 Spacer-s

Tools Required

Phillips Screwdriver



WARNINE

CAUTION!

This monitor desktop mount must be securely attached to the horizontal desk. If the mount is not properly installed it may fall, resulting in possible injury and/or damage.

Step 1



Install the Pole to the Desktop

Option A: Desk Clamp Install

Remove the 3pcs M5X20 bolts at the bottom of the pole(a) with Allen key, see Figure 1A.

1. Install the "c"-Clamp Brace(c) to the Pole (a) using 3pcs M5x20 Bolts , and tighten using the Allen Key(o) , see Figure 1.

2. Install the "c"-Clamp(b) to the pole assembly according to the thickness of the desktop. The thickness can be changed of three positions. Connect it using 2 pcs M8x12 Bolts(f), and tighten using the Allen Key(o). Tighten the "c"-Clamp to the desktop by twisting the plastic knob, see Figure 2.



Option B: Grommet Base Install



Existing Grommet Hole Installation

If the existing grommet hole comes with a plastic protector, remove it to ensure a flat surface before installing the desk mount.

Remove the 3pcs M5X20 bolts at the bottom of the pole(a) with Allen key, see Figure 1A.

1. Install the Grommet Base Plate(l) to the Pole(a) using 3 pcs M5x20 Bolts , and tighten using the Allen Key(o), see Figure 3.

2. Position the Pole(a) on the mounting surface and secure using the Support Plate (i), M10 Washer(j), Spring Washer(k), and M10 Bolt(h). Fasten the M10 Bolt using the provided Wrench(p), see Figure 4.



Step 1

Install the Pole to the Desktop

Option B: Grommet Base Install



Self Drilled Grommet Hole Installation

Remove the 3pcs M5X20 bolts at the bottom of the pole(a) with Allen key, see Figure 1A.

1. Position the Pole(a) on the mounting surface and mark the center hole. Drill a 3/8" (10mm) diameter hole at the marked position through the mounting surface.

2. Install the Grommet Base Plate(m) to the Pole(a) using 3pcs M5x20 Bolts(f), and tighten using the Allen Key(o), see Figure 5.


3. Position the Pole(a) on the mounting surface and secure using the Support Plate(j). M10 Washer(k), Spring Washer(l) and M10 Bolt(i), Fasten the M10 Bolt using the provided Wrench(p), see Figure 6.



Step 2


Install Arm to the Pole

Place the Swivel Arm(d) over the pole, and tighten with Allen Key (o)




Step 3

Attach the VESA Plate to the Monitor




For Monitor with Flat Back




For Monitor with Curved or
Recessed Back

Step 4

Slide the Monitor to the Head of Swivel Arm




Slide the monitor onto the head of
Swivel Arm(d) as the above diagram.




Install the security Nut . Make
sure the security nut is installed
before you rotate the monitor.

Step 5

Make the Necessary Adjustments



Adjust and tighten the bolt with the supplied Allen Key (o) to fix the tilt angle




If one monitor is lower, remove the Nut and turn the bolt counter-clockwise with supplied Allen key (O) to raise the monitor. Install the Nut after the adjustment.


Note: Never swivel forward or backward too much, accidental falling might occur.

Step 6

Manage the Wires and Store the Allen Keys on Wire Clip



Use the provided Allen Key (o) to make the necessary adjustments to each arm



Hold wires in place with a cable clip (Wire Clip – m)

Thank you for choosing our products!

- VISIT US AT MOUNT-IT.COM FOR PRODUCT REGISTRATION AND WARRANTY INFORMATION.
- CONTACT US AT SUPPORT@MOUNT-IT.COM OR 855-925-5668 FOR QUESTIONS OR COMMENTS.