



User's Guide

TV-IP612P
TV-IP612WN
1.02

CONTENTS

- ABOUT THIS USER’S GUIDE 1**
- INTRODUCTION 2**
 - Features and Benefits..... 2
 - Unpacking the Package 3
 - System Requirements 4
 - Default Settings 5
- Camera Hardware Components 6**
 - Front Panel Components..... 6
 - LED Indicators..... 6
 - Rear Panel Components 7
- INSTALLING THE CAMERA 9**
 - Attach the Metal Plate 9
 - Connect Ethernet Cable 10
 - Connect Power and Power On Camera..... 10
 - Reset Camera 11
- SECURITY12**
- APPLICATION13**
- USING THE UTILITY14**
 - SetupWizard 14
- USING THE CAMERA WEB MANAGER.....30**
 - Accessing the Camera Video Display 30**
 - Login..... 31
 - Setup - Web Configuration Utility..... 31
 - Wizard 32**
 - Step 1 Setup LAN Settings..... 33
 - Step 2 Setup Internet Settings 33
 - Step 3 Setup DDNS Settings 34
 - Step 4 Camera Name Settings..... 34
 - Step 5 Setup Time Zone 35
 - Step 6 Setup Complete 35
 - System..... 36**
 - Device Management 36
 - Time and Date..... 37
 - Network 38**
 - Network Setup 38
 - Port Settings..... 39
 - Wireless Setup 39
 - Selecting a SSID from the Site Survey..... 40
 - Dynamic Domain Name Service (DDNS) 40

Video Audio 41
Video and Audio..... 41
Video Profile 1-4 41
Audio Setup 42
Image Setup 42
ICR 44
Action 45
Recording 45
Recording Options 46
Scheduling 46
Snapshot 47
Email Settings 47
Preset Position 48
Camera Control 48
Digital Output..... 49
External Digital Input/Output Connectors 49
Trigger 50
Trigger Event 50
Motion Detection 51
Live Video 51
Drawing Mode:..... 51
Tools..... 52
Backup and Restore 52
Firmware Upgrade 52
Device Info..... 53
Device Info 53
Log..... 53
Viewing Video..... 54
Controlling the Camera 55

IPVIEW PRO 2.0 57
Launching IPView Pro 2.0 for the first time 57
Add a camera for monitoring..... 58
IPView Pro 2.0 User Interface..... 60
Display Controls 61
Live video display controls 63
Camera configuration with IPView Pro 2.0 64
Adding a Camera – Camera management..... 64
Removing a Camera..... 65
Schedule Recording with IPView Pro 2.0 66
Setup Motion Detection and Digital Input with IPView Pro 2.0 68
IPView Pro 2.0 Recording Options..... 69
IPView Pro 2.0 Miscellaneous Options..... 70

PLAYING VIDEO FILES ON A COMPUTER..... 71
Load Saved Video Files..... 72
Play Video Files..... 73
ffdshow 74

APPENDIX 80

A. Frequently Asked Questions 80

B. PING your IP Address 82

C. Troubleshooting..... 84

D. Time Zone Table 89

E.Technical Specifications 92

About This User's Guide

This User Guide provides instructions on how to install the TV-IP612P/W Wireless Network camera and use it for camera monitoring applications. Camera monitor applications are accessible through an Ethernet or 802.11b/g/n wireless local area network. The following chapters are included in this User Guide:

- Chapter 1, **Introduction**, provides general information about the Camera.
- Chapter 2, **Installing the Camera**, describes the hardware installation procedure for the Camera.
- Chapter 3, **Security**, explains the security features of the Camera.
- Chapter 4, **Application of the Camera**, provides an illustration of the Camera's applications.
- Chapter 5, **Using the Utility**, guides you through configuring the Camera with the Utility.
- Chapter 6, **Using the Camera Web Manager**, guides you through configuring the Camera with a Web Browser.
- Chapter 7, **IPView Pro**, helps you to install and use the software.
- Chapter 8, **Playing Video Files on a Computer**, shows you how to use the IPCamPlayer application to record and play back video recordings with the Camera.
- Chapter 9, **Appendix**.

Please note that the illustrations or setting values in this manual are **FOR YOUR REFERENCE ONLY**. The actual settings and values depend on your system and network. If you are not sure about the respective information, please ask your network administrator or information systems staff for help.

Introduction

Thank you for purchasing the TV-IP612P/TV-IP612WN Pan/Tilt/Zoom (Wireless) Internet Camera, a standalone system that can be connected directly to an Ethernet or Fast Ethernet connection. The TV-IP612WN also supports wireless transmissions based on the IEEE 802.11b/g/n standard. Compared to a conventional PC camera, the Pan/Tilt/Zoom Internet (Wireless) Camera features a built-in CPU and web-based solution that can provide a cost-effective way of transmitting real-time high-quality video images for monitoring. The Camera can be managed remotely, allowing you to use a Web browser to access the Camera from any notebook/desktop computer over an intranet or the Internet. The simple installation procedures and Web-based interface allows you to easily integrate the Camera into your network. With comprehensive application support, the Internet Camera is an ideal solution for remotely monitored, high quality and high performance video images.

Features and Benefits

Easy to use - The Camera is a standalone system with built-in CPU, no special hardware or software is required. The camera supports DirectX 9.0; therefore, the only requirement you need is the web browser software such as Internet Explorer 7.0 or above. Once you have a valid IP Address, just connect it and you can view video footage from your Camera. In addition, the Camera's pan/tilt/zoom function allows you to adjust the Camera for optimal viewing angles and zoom strength. You can pan the Camera to the left or right ($-165^{\circ} \sim +165^{\circ}$) and tilt the Camera up or down ($-84^{\circ} \sim +31^{\circ}$) using the Web Configuration Utility. Further, you can also zoom up to a maximum of 10x optical zoom.

Motion detection and event triggered digital image or video recording – Use the Motion Detection to take a snapshot or digital video record of objects that move through a selected area of the video display.

Supports variety of platforms - The camera supports TCP/IP networking, SMTP e-mail, HTTP and other Internet related protocols. It can be utilized in a mixed operating system environment, including Windows XP/Vista/7. Moreover, it can be integrated easily into other www/ Intranet applications.

Video Encoding The TV-IP612P/TV-IP612WN provides you with selectable video encoding formats that are able to efficiently utilize bandwidth. Using selectable video compression such as MJPEG, MPEG-4 and H.264 codecs, a reduction in bandwidth and storage space can be achieved. By using, for example, the H.264 codec over MJPEG of 80 percent is achievable.

Web configuration - Applying a standard web browser, the administrator can configure and manage the camera directly from its own web page via the Intranet or Internet. Up to 64 user accounts are permitted with privilege settings controlled by the administrator.

Remote Utility - The powerful IPView Pro 2.0 application assigns the administrator with a pre-defined user ID and password, allowing the administrator to modify the camera settings from the remote site via Intranet or Internet. When new firmware is available, you can also upgrade remotely over the network for added convenience. Users are also allowed to monitor the image, and take snapshots.

Broad Range of Applications - With today's high-speed Internet services, the Camera can provide the ideal solution for live video images over the Intranet and Internet for remote monitoring. The Camera allows remote access from a Web-browser for live image viewing and

allows the Administrator to manage and control the Camera from anywhere in the World at anytime. The Camera can be used to monitor many different objects and places, including homes, offices, banks, hospitals, child-care centers, amusement parks and all kinds of industrial and public monitoring tasks. The Camera can also be used to detect intruders, capture still images for archiving and many other applications.

Remote Surveillance The TV-IP612P/TV-IP612WN is 3GPP compatible or in other words it supports mobile surveillance where a live feed from the camera can be viewed on a compatible 3G cellular network connected phone or other smart cellular network device. The device must be capable of supporting Real Time Streaming Protocol (RTSP) to enable you to monitor your video feed from any remote location supporting 3G protocols.

Local A/V Output The TV-IP612P/TV-IP612WN is equipped with a A/V output which allows you to connect it directly to a TV or VCR to view or record the camera's video. The Audio from the A/V output jack can be connected directly to a local speaker in order to provide audio to anyone within hearing range of the camera. This way a camera administrator can speak directly to anyone nearby the camera.

Input/Output Pins The camera supports industry standard input from the connection of various external devices including alarm relays, switches, and IR motion sensors. This can then further be associated with industry standard output to alarm devices that can be programmed based on the input triggers.

Multiple Protocol Support The camera further supports multiple protocol platforms such as: FTP, SMTP, NTP, HTTP, UPnP and DDNS.

Unpacking the Package

Open the shipping carton and carefully remove all items. Check that you have the following:

- One TV-IP612P or TV-IP612WN Internet Camera Server
- Two Detachable Antenna (TV-IP612WN only)
- One Multi-Language Quick Installation Guide
- One CD-ROM (Utility & User's Guide)
- One External Power Adapter (12V DC, 2A)
- One RJ-45 Ethernet Cable
- One Metal Mounting Plate
- 2x M3 6mm Screws for screwing the Camera to the Metal Plate
- 5x M3 16mm Screws for mounting the Camera to a wall or ceiling
- Audio/Video Cable

If any packaging content is damaged or missing, please contact your local dealer immediately. Also, keep the box and packing materials in case future shipment is necessary.



CAUTION: The Camera must be used with the power adapter included with the device.

System Requirements

Networking

- Local Area Network: 10Base-T Ethernet or 100Base-TX Fast Ethernet
- Wireless Local Area Network: IEEE 802.11b/g/n Wireless LAN (TV-IP612WN only)

Computer

- CPU: P4 2.8GHz or above
- Memory: 512 MB or above
- VGA Resolution: 1024 x 768 or above (Independent Display Card recommended)
- Network Card
 - o For cabled connections: 10BASE-T Ethernet or 100BASE-TX Fast Ethernet Network Interface Card
 - o For wireless connections: 802.11b/g/n series Wireless Interface Card
- CD-ROM Drive for Setup Wizard on Installation CD-ROM
- IPView Pro 2.0 Application Users must use Microsoft® Windows® XP, Vista, and 7 Operating System with:
 - o Internet Explorer 6.0 or above with DirectX9.0 or
 - o Mozilla Firefox and Apple Safari with Java Applet requires JVM (J2SE 1.5 or later, or JRE (J2SE) 6.0 or later).



NOTE: When you connect multiple cameras and monitor their images synchronously, it is recommended to use a high performance system, such as a Pentium 4 2.8GHz PC.

Default Settings

Use the default settings to access the web-based management software and live video display.

Default configuration settings	
Username	This is the Username you will be prompted to enter when you access the TV-IP612P/WN configuration screens using a Web browser. The default Username is admin .
Password	This is the Password you will be prompted to enter when you access the configuration windows using a Web browser. The default Password is admin .
IP address	This is the IP address you will enter into the Address field of your Web browser to access the camera monitor screen and configuration menus using a Web Browser. The camera uses DHCP for IP settings by default. If a DHCP server is not detected, the default IP address is 192.168.10.30. (Make sure your computer is configured to belong to the 192.168.10.X subnet if using the default IP address of the camera.)
Subnet Mask	The default subnet mask is 255.255.255.0.

Camera Hardware Components

This section provides information about the Camera’s hardware components:

Front Panel Components




Front panel of TV-IP612P/W

LED Indicators

LNK	This LED indicator lights steady orange when a valid Ethernet link is established. It blinks orange when traffic is received or transmitted through the Ethernet link.
PWR	This LED indicator lights blue when the camera is powered on. It remains dark when powered off.
Microphone	The microphone allows you to listen, from the monitoring computer, to the local audio near the camera.

Rear Panel Components

The power connection to the camera when fitted with the Infrared lens is split between the camera body and lens using the power connection adapter cable attached to the infrared lens. All other cables connect to the camera at the rear panel.



Rear Panel view of TV-IP612P/W

WPS	Press this button to enable Wireless Protected Setup so that you can automatically connect with a WPS enabled wireless device such as a router or access point.
Power receptacle	Connect power adapter shipped with the camera and plug into suitable power source.
Ethernet Port	Connect to Ethernet LAN. The port is auto MDI-II/MDI-X and auto-negotiation for port speed.
IO Connectors	This terminal block has one input pair and one output pair of pins to connect external input/output devices.
AV Out / Speaker Out	Connect this Audio/Video output jack with the supplied cable so that you can view or record the live video feed on a local TV or VCR. You can also connect audio to a local speaker for local audio reproduction.

MIC	Used this jack to connect and record audio from an external microphone.
Reset Button	Use to reset device to factory default settings including IP address and administrator user name and password.
Antennas	A threaded post is used for attaching the antenna. Fasten the antenna securely to the post.



Installing the Camera

The camera is intended for indoor use. The camera, the power adapter and power source should be protected from water and moisture, excessive heat, direct sunlight and cold. Make sure the power adapter and its cord and the Ethernet cable are safely arranged so they do not create a tripping hazard and will not be disturbed by people or objects moving past.

Attach the Metal Plate

To attach the metal plate carry out the following:

1. Slide the metal plate onto the base of the Camera, making sure that the three screws on the plate align with the three holes on the base of the Camera.
2. Secure the metal plate to the base of the Camera by twisting the camera to lock it.
3. The Camera can now be mounted to the ceiling or a wall. See the diagram below for more information.



- Install the Camera to the ceiling using the 4 ceiling screws (❶);
or
- Install the Camera using the two wall screws (❷).

Connect Ethernet Cable

To connect the camera to your network, connect a Category 5 or better Ethernet cable to the network cable connector located on the camera's left side panel, and then attach it to the network. The Ethernet port will automatically detect and adjust to the speed (10 or 100 Mbps) and polarity (MDI-II or MDI-X) of the connection.



Connect Power and Power On Camera

To provide power to the camera, connect the AC power adapter to the DC power input connector, also located on the camera's left side panel, and then plug it to the electrical outlet. As with any electrical device, make sure the power source and camera are located in an area where it is not going to get wet or present an electrical hazard.



CAUTION: The Camera must be used with the power adapter included with the device.

Reset Camera

A manual reset can be conducted by following the procedure below. The reset button is located on the rear panel of the camera. To reset the system settings to factory defaults, please follow these steps:

1. Use a paper clip or similar object to hold down the reset button for three seconds. The reset button is located on the rear panel of the device. See the Rear Panel Components picture above to locate the reset button.
2. Release the reset button and the Power LED will begin to flash, indicating that the Camera is reverting back to factory settings.

Upon restarting the camera loads the factory default configuration settings. The default IP address **192.168.10.30** and subnet mask **255.255.255.0** will be applied unless a DHCP server is actively connected to the network. If using the TV-IP612WN Wireless Camera, the default SSID is "TRENDNet". The administrator's default user name is **admin** and the password is **admin**. Use the Setup Wizard shipped with the camera to reconfigure it or access it through the web-based management software.

Security


To ensure the highest level of security and prevent unauthorized usage of the Camera, the Administrator account has exclusive access to the camera's configuration settings. The Administrator account can create up to 20 users. A User only has access to the Live View portion of the browser software to view and record video. Access to the Camera is strictly restricted to User's that have been created in the **Setup-System-Device Management** menu.

Application

The TV-IP612P / TV-IP612WN camera can be applied in a wide range of applications, including:

- Monitoring of local and remote places and objects, such as construction sites, hospitals, amusement parks, schools and day-care centers by using a web browser.
- Using the IPView Pro 2 application to capture singles frame images.
- Configuring the Camera to upload images to an FTP Server or sending e-mail messages with single frame images.

The diagram below shows the Camera being used for a number of different applications using the IPView Pro applications and includes basic information that may assist you with installing and configuring the Camera:



Using the Utility

This chapter describes the software utilities for the IP Camera, including how to set up your Camera with the utility. The **SetupWizard** has a user-friendly interface that allows you to setup the Camera easily.

SetupWizard

This section describes how to install the SetupWizard and how to use the SetupWizard to setup and install your Camera quickly and easily. To install the SetupWizard on a system running Windows, launch the SetupWizard on the installation CD-ROM and follow the setup instructions.


Installing the SetupWizard

1. Click the **Setup Wizard** button for the Auto-Run menu screen. The InstallShield Wizard will appear:
 - Click **Next >** to continue.




2. The next window asks you whether you want to accept the License Agreement or not.

- If you agree with the Licensing Agreement, click the **I Agree** radio button and the **Next >** button.
- If you don't agree with the Licensing Agreement, click the **I Do Not Agree** radio button to exit the install wizard.




3. The following window appears asking you to choose the desired installation location. By default the destination location is C:\Program Files\TRENDnet\SetupWizard.

- Click the **Browse** button to change the default installation location.
- Click the **Everyone** radio button to make the SetupWizard available to all users on your Computer.
- Click the **Just me** radio button to only make the application available to the user who is running the SetupWizard installation.
- Click **Next >** to continue.




4. The following window appears informing you that the installation is ready to start:

- Click **Next >** to start the Installation.




5. The software will start to install. The following window appears, showing the progress of the installation:



6. When installation is complete the following window appears to confirm that the SetupWizard has installed successfully:

- Click **Close** to exit the installation



After installing the SetupWizard, the application program for the Camera is automatically installed on your computer.

Launching the SetupWizard

To launch the SetupWizard, click the SetupWizard icon on your desktop or go to **Start > Programs > TRENDnet > SetupWizard > SetupWizard** to start the application.

SetupWizard- Install Your Camera



- Connect the camera to your LAN using the provided RJ45 cable.
- Connect the AC Power Adapter to the back of the camera and to a live power socket.
- Click **Next** to continue.

SetupWizard- Select Your Camera

The following screen appears showing the cameras that have been found on your network:



TRENDnet Setup Wizard

Select Your Camera

Please select a camera in the camera list then click "Next" or try to link it with web browser. If you can't find specified camera, please check your camera's wire link then click "Re-scan" again.

Name	IP Address	Model	MAC
TV-IP612P	192.168.10.30	TV-IP612P	005C75388684

Re-Scan Link Next Exit

Copyright © 2010 TRENDnet, Inc. All rights reserved.

- Click on the camera you want to configure.
- Click **Next** to continue.

SetupWizard- Authentication

On the following screen type in the ID and Password that you will use to configuring the camera settings:

The image shows the 'Authentication' screen of the Trendnet Setup Wizard. The interface has a blue header with the 'TRENDnet' logo on the left and 'Setup Wizard' on the right. The main content area is light blue and contains the title 'Authentication' followed by instructions: 'Please enter ID and password to verify authorization for setting up camera. Click button "Next" to check. Or click button "Previous" to select another camera.' Below this, there are two input fields: 'ID' with the text 'admin' and 'Password' with masked characters '.....'. To the right of the password field is the text '(Default : admin)'. At the bottom of the main area, there is a paragraph: 'The Wizard will help you to discover if there is a DHCP server in your network environment, so please click the "Unblock" button if you see a Windows Security Alert dialog.' Below this paragraph are three buttons: 'Previous', 'Next', and 'Exit'. The footer of the window contains the text 'Copyright © 2009 TRENDnet. All Rights Reserved.'

- Type a *User ID* in the **ID** field.
- Type a *password* for the User in the **Password** field.
- Click **Next** to continue.

SetupWizard- Other Settings

The screen below allows you to set the camera name and the camera's time settings.



The screenshot shows the 'Setup Wizard' window for a Trendnet camera. The title bar says 'Setup Wizard'. The main content area is titled 'Other Settings' and contains the following text: 'You can have a name for the camera. And you can also adjust the camera's clock by input the current time on "Camera time" option. Click button "Next" to continue setting up.' Below this text are three input fields: 'Camera Name' with the value 'TV-IP612P', 'Camera Time' with a date dropdown set to '2010/01/01', and a time dropdown set to '12:00:00'. At the bottom of the form are four buttons: 'Copy Local Time', 'Previous', 'Next', and 'Exit'. The footer of the window reads 'Copyright © 2010 TRENDnet, Inc. All rights reserved.'

- Type a name to help you identify the camera in the **Camera Name** field.
- Set the camera date and time from the **Camera Time** drop-down menus. To use the time settings from your computer, click the **Copy Local Time** button.
- Click **Next** when you have finished configuring the other settings.

SetupWizard- Change Password

The following screen allows you to change the default admin password:



The screenshot shows the 'Change Password' screen in the TRENDnet Setup Wizard. The interface has a blue header with the TRENDnet logo on the left and 'Setup Wizard' on the right. The main content area is light blue and contains the title 'Change Password' and a paragraph: 'You can change the password here to secure your camera from being accessed by others. Leave the checkbox unchecked to skip this step.' Below this is a checkbox labeled 'Change Password', which is currently unchecked. Under the checkbox are two text input fields: 'New Password' and 'Confirm Password'. At the bottom of the form are three buttons: 'Previous', 'Next', and 'Exit'. A copyright notice 'Copyright © 2009 TRENDnet. All Rights Reserved.' is visible in the bottom right corner of the window.

Carry out the following if you want to change the admin password:

- Tick the **Change Password** checkbox
- Type in a *New Password* in the **New Password** field and confirm it in the **Confirm Password** field
- Click the **Next** button to proceed to the next **Setup** window


If you don't want to change the admin password, leave the checkbox un-ticked and click **Next**.

SetupWizard- Select a Connection Option

The following window allows you to specify the connection method used by your camera network.

Click the radio button of the network environment your camera is connected to. The available options are:


- **PPPoE**
- **DHCP**
- **Fixed IP**



The screenshot shows the 'Setup Wizard' window for a TRENDnet camera. The title bar includes the TRENDnet logo and the text 'Setup Wizard'. The main content area is titled 'Select a Connection Option' and contains the instruction: 'Please select the connection option by your camera network environment. If you don't know how to choose, leave the option selected as default.' There are three radio button options: 'PPPoE' (with a description about DSL Modem and ISP authentication), 'DHCP' (with a description about router and DHCP), and 'Fixed IP' (with a description about DSL Modem and ISP-supplied IP). The 'Fixed IP' option is currently selected. At the bottom of the window are three buttons: 'Previous', 'Next', and 'Exit'. The footer of the window states 'Copyright © 2009 TRENDnet. All Rights Reserved.'

SetupWizard – Select a Connection Option - PPPoE

If your connection method is PPPoE, click the **PPPoE** radio button and click **Next**:



The screenshot shows the 'Select a Connection Option' screen of the TrendNet Setup Wizard. The title bar includes the TrendNet logo and 'Setup Wizard'. The main content area has a heading 'Select a Connection Option' followed by instructions: 'Please select the connection option by your camera network environment. If you don't know how to choose, leave the option selected as default.' There are three radio button options: 'PPPoE' (selected), 'DHCP', and 'Fixed IP'. Each option has a descriptive text in parentheses. At the bottom, there are three buttons: 'Previous', 'Next', and 'Exit'. A copyright notice 'Copyright © 2009 TRENDnet. All Rights Reserved.' is at the bottom right.

TRENDnet Setup Wizard

Select a Connection Option


Please select the connection option by your camera network environment. If you don't know how to choose, leave the option selected as default.

- ☒ **PPPoE** (Select this option if your camera is directly connected to a DSL Modem and your ISP requires a PPPoE authentication to the Internet.)
- ☐ **DHCP** (Select this option if your camera is connected to a router and DHCP is enabled.)
- ☐ **Fixed IP** (Select this option if your camera is directly connected to a DSL Modem and your ISP has supplied you with a fixed IP for your Internet connection.)

Previous Next Exit

Copyright © 2009 TRENDnet. All Rights Reserved.

The following window appears:



The screenshot shows the 'Authentication for PPPoE Connection' screen of the TrendNet Setup Wizard. The title bar includes the TrendNet logo and 'Setup Wizard'. The main content area has a heading 'Authentication for PPPoE Connection' followed by instructions: 'Please enter username and password while ensuring that your camera is directly attached to your modem. Click button "Next" to continue setting up. Or click button "Previous" to select another network environment.' There are three text input fields: 'User Name', 'Password', and 'Confirm Password'. At the bottom, there are three buttons: 'Previous', 'Next', and 'Exit'. A copyright notice 'Copyright © 2009 TRENDnet. All Rights Reserved.' is at the bottom right.

TRENDnet Setup Wizard

Authentication for PPPoE Connection

Please enter username and password while ensuring that your camera is directly attached to your modem. Click button "Next" to continue setting up. Or click button "Previous" to select another network environment.

User Name
[Text Field]

Password
[Text Field]

Confirm Password
[Text Field]


Previous Next Exit

Copyright © 2009 TRENDnet. All Rights Reserved.

- Type the *User Name* used to connect to your PPPoE connection in the **User Name** field.
- Type the *Password* of the PPPoE User Name in the **Password** field and confirm it in the **Confirm Password** field.
- Click **Next** to proceed to the next setup window.

SetupWizard- Select a Connection Option- DHCP

If your connection method is DHCP, click the **DHCP** radio button and click **Next**:




The screenshot shows the Trendnet Setup Wizard interface. At the top left is the Trendnet logo, and at the top right is the text "Setup Wizard". The main content area is titled "Select a Connection Option" and includes a paragraph: "Please select the connection option by your camera network environment. If you don't know how to choose, leave the option selected as default." Below this, there are three radio button options:

- ☐ PPPoE (Select this option if your camera is directly connected to a DSL Modem and your ISP requires a PPPoE authentication to the Internet.)
- ☒ DHCP (Select this option if your camera is connected to a router and DHCP is enabled.)
- ☐ Fixed IP (Select this option if your camera is directly connected to a DSL Modem and your ISP has supplied you with a fixed IP for your Internet connection.)

At the bottom of the form are three buttons: "Previous", "Next", and "Exit". The "Next" button is highlighted. At the bottom right of the window, there is a copyright notice: "Copyright © 2009 TRENDnet. All Rights Reserved."

SetupWizard- Select a Connection Option- Fixed IP

If your connection method is Fixed IP, click the **Fixed IP** radio button:



TRENDnet Setup Wizard

Select a Connection Option


Please select the connection option by your camera network environment. If you don't know how to choose, leave the option selected as default.

- ☐ PPPoE (Select this option if your camera is directly connected to a DSL Modem and your ISP requires a PPPoE authentication to the Internet.)
- ☐ DHCP (Select this option if your camera is connected to a router and DHCP is enabled.)
- ☒ Fixed IP (Select this option if your camera is directly connected to a DSL Modem and your ISP has supplied you with a fixed IP for your Internet connection.)

Previous Next Exit

Copyright © 2009 TRENDnet. All Rights Reserved.

The following window appears:



TRENDnet Setup Wizard

Network Configuration

Please input correct information. You can click button "Auto" to let IP camera configured automatically. Click button "Next" to continue setting up.

IP Address	10.73.87.99
Subnet Mask	255.0.0.0
Default Gateway	10.1.1.254
Primary DNS	0.0.0.0
Secondary DNS	0.0.0.0

Auto Previous Next Exit

Copyright © 2009 TRENDnet. All Rights Reserved.

- Type in the *IP Address*, *Subnet Mask*, *Default Gateway*, *Primary DNS Server IP address* and *Secondary DNS Server IP Address* in the appropriate fields.
- Click **Next** to proceed to the next setup window.

SetupWizard- Setup Wireless (For TV-IP612WN only)

After choosing your connection method, the following window appears:



- Choose if you want to connect to your camera using the wireless connection or not by clicking the appropriate radio button.
- Click **Next** to continue.

SetupWizard- Setup Wireless (For TV-IP612WN only)

If you selected the option to use a wireless connection to connect to your camera the following window appears:

TRENDnet Setup Wizard

Manually Setup Wireless

In this section, you can setup the camera's wireless network interface settings.
Click button "Next" to continue setting up.

Available AP	<Current>
SSID	TRENDnet
Wireless Mode	Infrastructure
Channel	Auto
Authentication	Open/Shared
Encryption	Disabled
Key	

Re-Scan Previous Next Exit

Copyright © 2009 TRENDnet. All Rights Reserved.

- Choose the *Access Point* you want to connect the camera to from the **Available AP** drop-down menu. If the Wireless LAN you want to connect to doesn't appear in the **Available AP** list, click the **Re-Scan** button to scan for additional Wireless LAN's.
- Type the *SSID* of the WLAN you want to connect to in the **SSID** field.
- Choose the *Wireless Mode* of your WLAN from the **Wireless Mode** drop-down menu.
- Choose the *Channel* of your WLAN from the **Channel** drop-down menu.
- Choose the *Authentication method* of your WLAN from the **Authentication** drop-down menu.
- Choose the *Encryption method* of your WLAN from the **Encryption** drop-down menu.
- Type the *Encryption Key* used by your Wireless LAN in the **Key** field.
- When you have finished configuring the wireless settings, click **Next** to continue to the next setup window.

SetupWizard- Setting Up The Camera

The following window appears, summarizing the network settings of your camera:



The screenshot shows the 'Setting Up The Camera' window of the Trendnet Setup Wizard. It is divided into two columns: 'Wired' and 'Wireless'. The 'Wired' column contains fields for IP Address (10.73.87.99), Subnet Mask (255.0.0.0), Default Gateway (10.1.1.254), Primary DNS (172.19.10.100), Secondary DNS (172.19.10.99), Camera Name (TV-IP600W), Camera Date (2009/01/07), and Camera Time (16:24:47). The 'Wireless' column contains fields for SSID (TRENDnet), Wireless Mode (Infrastructure), Channel (Auto), Authentication (Open/Shared), Encryption (Disabled), and Key (empty). At the bottom, there are three buttons: 'Previous', 'Next', and 'Exit'. The copyright notice at the bottom right reads 'Copyright © 2009 TRENDnet. All Rights Reserved.'

Setting Up The Camera	
Wired :	
IP Address	10.73.87.99
Subnet Mask	255.0.0.0
Default Gateway	10.1.1.254
Primary DNS	172.19.10.100
Secondary DNS	172.19.10.99
Camera Name :	TV-IP600W
Camera Date :	2009/01/07
Camera Time :	16:24:47
Wireless :	
SSID	TRENDnet
Wireless Mode	Infrastructure
Channel	Auto
Authentication	Open/Shared
Encryption	Disabled
Key	


Previous Next Exit

Copyright © 2009 TRENDnet. All Rights Reserved.

- When you have finished setting up the Camera click the **Next** button. To make any changes to your Camera settings, click the **Previous** button.

SetupWizard- Camera Restart

The following window appears, indicating that the camera is restarting:




The screenshot shows the 'Camera Restart' window of the Trendnet Setup Wizard. It features a large yellow progress bar at the top, which is partially filled with a blue segment on the left. Below the progress bar, the text reads 'Please wait for a minute while setting up the camera.' The copyright notice at the bottom right reads 'Copyright © 2009 TRENDnet. All Rights Reserved.'

Please wait for a minute while setting up the camera.

Copyright © 2009 TRENDnet. All Rights Reserved.

SetupWizard- Complete

After the camera has restarted, the following window will appear:



- Click the hyper-link to connect to the camera web interface.
- If you want to setup an additional camera, click the **Setup Another Camera** button.
- When you have finished, click the **Exit** button to close the Setup Wizard.

Using the Camera Web Manager

The camera is easy to use and manage. Use a normal web browser to access the camera's live video display, as well as the configuration software. It is recommended to check and make sure the computer can access and use the camera before placing it in the location where it will be used, especially if it is mounted to a ceiling or other area that is difficult to physically access.

For the initial setup, use the Setup Wizard program located on the TV-IP612P/WN CD-ROM included with the camera. Use the IPCam Wizard to assign an IP address and other network settings. Once the camera has an IP address, follow the instructions below to access the camera's web management interface used to manage the camera and its video display.

Accessing the Camera Video Display

If the camera is used on a network with an active DHCP server, the camera will detect it and obtain an IP address. If you are using the camera on a network with a DHCP server it is necessary to first determine what the IP address of camera is. To do this, follow the instructions in the Quick Installation Guide to launch the Setup Wizard to link to the camera.



NOTE: If your network uses DHCP or has an active DHCP server running, use the Setup Wizard utility on the installation CD-ROM shipped with the camera to first access the camera. Once it is accessed, you can change the IP address or continue to use the DHCP assigned address as preferred. See the Quick Installation Guide for instructions on using the Setup Wizard utility.

If your network does not use a DHCP server, the camera will use a default IP address of 192.168.10.30. Use this address to access the web-based management software. Use a web browser and type in **http://** followed by the default IP address, **192.168.10.30** in the address bar of the browser and press the **Enter** key. The URL in the address bar should read:
http://192.168.10.30

If the login dialog does not appear, check the proxy server settings on your browser.



NOTE: The wrong proxy server settings on your browser can prevent connection to the web manager. If you are having trouble connecting to the web interface of the VLAN Switch, configure the proxy settings to bypass the proxy server or disable use of proxy servers and try to connect again.


To check proxy setting for Windows Internet Explorer:

1. In Windows, click on the **Start** button, go to **Settings** and choose **Control Panel**.
2. In the **Control Panel** window, double-click on the **Internet Options** icon. (Alternatively you can access this **Internet Options** menu using the **Tools** pull-down menu in Internet Explorer.)
3. Click the **Connections** tab and click on the **LAN Settings** button.
4. Verify that the "Use proxy server" option is NOT checked. If it is checked, click in the checked box to deselect the option and click **OK**.

Login


To access the web manager directly from a computer or on a network without a DHCP server running, use the default IP address of the camera in the browser address entry to access the web manager. Type **http://192.168.10.30** in the address bar and press **Enter**. The login dialog appears when accessing the camera.

Type the default user name “admin”, default password “admin” and click on the **OK** button to access the camera’s management interface.



Setup - Web Configuration Utility


After successfully logging in, the camera Live View screen will appear. Select **Setup** to enter into the configuration menu screen.



Live View Screen of the camera

Wizard

The first menu to appear after clicking on Setup is the the automatic setup wizard. You can use this wizard to configure settings for your camera's Name, LAN and Internet, DDNS and Time/Date. Click on **Next** to start the wizard otherwise select another menu choice from the left hand menu buttons.



System menu in Administration directory

The different menus that are available are presented and described in the following pages.

Step 1 Setup LAN Settings

Select the **DHCP Connection** option if your wired or wireless connection will use a dynamically assigned IP address

Select the **Static IP Address** option and then manual enter in the network settings your camera will use.




The screenshot shows the 'Step 1: Setup LAN Settings' web interface. It has a title bar and a main content area. The title bar says 'Step 1: Setup LAN Settings'. The main content area has a paragraph of instructions: 'Please select whether your camera will connect to the Internet with a DHCP connection or Static IP address. If your camera is connected to a router, or you are unsure which settings to pick, we recommends that you keep the default selection of DHCP connection. Otherwise, click on Static IP address to manually assign and IP address before clicking on the Next button.' Below this are two radio buttons: 'DHCP Connection' (selected) and 'Static IP Address'. Below the radio buttons are five input fields: 'IP Address' (192.168.10.30), 'Subnet Mask' (255.255.255.0), 'Default Gateway' (192.168.10.30), 'Primary DNS' (empty), and 'Secondary DNS' (empty). At the bottom are three buttons: 'Back', 'Next', and 'Cancel'.

Click **Next** to continue to step 2

Step 2 Setup Internet Settings

To connect a camera directly to the internet using a PPPOE connection enter the username and password here. Your ISP should supply you with the credentials you need. You do not need to configure this setting if the camera is connected behind either a router or gateway.



The screenshot shows the 'Step 2: Setup Internet Settings' web interface. It has a title bar and a main content area. The title bar says 'Step 2: Setup Internet Settings'. The main content area has a paragraph of instructions: 'Please enter your ISP Username and Password in the case that your ISP is using PPPoE and then click on the Next button. Please contact your ISP if you do not know your Username and Password.' Below this is a checkbox labeled 'Enabled'. Below the checkbox are two input fields: 'User Name' (with a placeholder example 'e.g. 123456@hinet.net') and 'Password'. At the bottom are three buttons: 'Back', 'Next', and 'Cancel'.

Click **Next** to continue to step 3

Step 3 Setup DDNS Settings

To synchronize the public IP address of the Modem, when it has been modified, use the DDNS service settings. You must supply the Username and Password when utilizing the DDNS service.

Server Address: Select your service providers Dynamic DNS web address..

Host name: Enter the Domain name you were given from the DDNS service provider


User name: Enter the account user name your DDNS service provider has given you.

Password: Enter the password associated with the DDNS account user name.

Verify Password: Repeat the password as entered above to verify it.

Timeout: - This setting is the notification period in hours when the camera sends a current global IP address update to the DDNS server configured above. The default is 576 hours. You can setup how often the camera notifies the DDNS server of its current global IP address. By default this is 576 hours.


Click **Next** to continue to step 4



The screenshot shows the 'Step 3: Setup DDNS Settings' web interface. At the top, it says 'Step 3: Setup DDNS Settings' and provides instructions: 'If you have a Dynamic DNS account and would like the camera to update your IP address automatically, enable DDNS and enter in your host information below. Please click on the Next button to continue.' Below this, there is a checkbox labeled 'Enable'. To the right of the checkbox is a dropdown menu labeled 'Select Dynamic DNS Server'. Below the checkbox and dropdown are five text input fields labeled 'Server Address', 'Host Name', 'User Name', 'Password', and 'Verify Password'. Below these fields is a 'Timeout' field with the value '576' and the unit '(Hours)'. At the bottom of the form are three buttons: 'Back', 'Next', and 'Cancel'.

Step 4 Camera Name Settings

You can assign the camera a name here. Please enter the name and then click **next** to continue to step 5.



The screenshot shows the 'Step 4: Camera Name Settings' web interface. At the top, it says 'Step 4: Camera Name Settings' and provides instructions: 'We recommends that you rename your camera for easy accessibility. You can then identify and connect to your camera via this name. Please assign a name of your choice before clicking on the Next button.' Below this, there is a text input field labeled 'Camera Name' with the value 'TV-IP612WN'. At the bottom of the form are three buttons: 'Back', 'Next', and 'Cancel'.

Step 5 Setup Time Zone

Use this step to configure the Time and Date, the Time Zone and the Daylight savings configuration of the camera.

Time Zone: Select the Time Zone for your camera in the drop-down list.

Enable Daylight Saving: Select this to enable Daylight Savings for the Time Zone you have chosen above. This will automatically set daylight savings time depending on the date and time for each time zone.

Keep current date and time: Select this choice to prevent any time and date changes from the current setting.

Synchronize with NTP Server: Select this choice to enable NTP time slaved to the NTP server identified below.

NTP Server: Enter the NTP server address or hostname

Set date and time manually: Use this setting and the entry boxes below to enter the date and time desired as a manual configuration.

Copy Your Computer's Time Settings: Click this button to automatically set the time and date based on your computer's settings.

Click **Next** to go to Step 6

Step 5: Setup Time Zone

Please configure the correct time to ensure that all events are triggered, captured and scheduled at the correct time and day and then click on the Next button.

Time Zone: (GMT-08:00) Pacific Time (US & Canada) [v]

☒ Enable Daylight Saving

☐ Keep current date and time

☐ Synchronize with NTP Server

NTP Server: [text box]

☐ Set date and time manually

Year: 2010 [v] Month: 7 [v] Day: 5 [v]

Hour: 15 [v] Minute: 51 [v] Second: 55 [v]

Copy Your Computer's Time Settings [button]

[Back] [Next] [Cancel]

Step 6 Setup Complete

Carefully review your settings and then click Apply to finish the wizard.

Step 6: Setup complete

Below is a summary of your camera settings. Click on the Back button to review or modify settings or click on the Apply button if all settings are correct. It is recommended to note down these settings in order to access your camera on the network or via your web browser.

IP Address	192.168.10.30
IP Camera Name	TV-IP612WN
Time Zone	(GMT-08:00) Pacific Time (US & Canada)
DDNS	Disable
PPPoE	Disable

[Back] [Apply] [Cancel]

The camera will reboot to apply the new settings:

Step 6: Setup complete

Success

Web Server has been reboot, please wait for 37 seconds ...

[Back] [Apply] [Cancel]

System

The system menu item configures the devices users, associated passwords, device name, OSD settings, and LED light control.

Device Management

Admin Password Settings:

Use the fields to change the administrator password used to access the System Administration settings. Enter, a *password* in the **New Password** field and confirm the *password* in the **Retype Password** field.

Add User Account:

Enter the new users name and password twice; then click add to configure the new user for accessing the Live View video stream. A maximum of 20 users can be configured.

User List:

Click on the pull-down menu to view the current users configured for the camera. To delete a user select the user from the pull-down list and click on the delete button.

Device Settings:

Camera Name: Enter the name desired for the camera up to a maximum of 36 characters.

Enable OSD: Check this box to provide On-Screen Display on the Video Stream from the camera of the following items.

Label: Enter the desired text to identify the camera.

Show Time: check this to show the current time and date in the video display from the camera

LED light: Clicking the off selection turns the LEDs on the camera off even though the camera is in operation.

Calibrate the Device

Clicking this button will reset the camera to the home position and default settings after a series of camera checks and movements. Use this in case the camera was moved manually by hand or otherwise.

The screenshot shows the 'Device Management' web interface. It is divided into several sections: 'Admin Password Setting' with fields for 'New Password' and 'Retype Password' (both with a '30 characters maximum' limit) and a 'Save' button; 'Add User Account' with fields for 'User Name', 'New Password', and 'Retype Password' (all with '30 characters maximum' limits) and an 'Add' button (with a '20 users maximum' limit); 'User List' with a 'User Name' dropdown menu and a 'Delete' button; 'Device Setting' with fields for 'Camera Name' (36 characters maximum) and 'Label' (30 characters maximum), a checked 'Enable OSD' checkbox, a 'Show time' checkbox, and an 'LED light' section with 'On' and 'Off' radio buttons and a 'Save' button. At the bottom, there are two 'Calibrate the Device' buttons.

Time and Date

Time Configuration

Time Zone: Select the Time Zone for your camera in the drop-down list.

Enable Daylight Saving: Select this to enable Daylight Savings for the Time Zone you have chosen above. This will automatically set daylight savings time depending on the date and time for each time zone.

Auto Daylight Savings: This setting automatically is enabled when you check Enable Daylight Savings. Otherwise this setting is disabled when Set date and time manually is enabled below.

Set Daylight Savings Manually: Click this radio button and use the Offset, Start Time and End Time entry boxes below to manually set Daylight Savings for the specific range of date and time.

Offset: The time adjustment in hours forward or back (+/-).

Start Time: When the time Offset will be effected. (Daylight Savings Time).

End Time: When the time Offset is no longer in effect (Standard Time).

Automatic Time Configuration

Synchronize with NTP Server: Select this choice to enable NTP time slaved to the NTP server identified below.

NTP Server: Enter the NTP server address or hostname

Set date and time manually

Use these settings to manually enter the time and date for the camera.

Copy Your Computer's Time Settings: Press this button to automatically copy the current computers time and date settings to the camera configuration.

Click **Ok** to continue to save your settings.

Network

Use the menu selections in this section to configure the network settings for both wired and wireless LAN setups (TV-IP612WN only) of the camera.

Network Setup

DHCP Connection: Select this option to automatically configure the Camera IP settings from a DHCP server.

Static IP Address: Select this option to manually configure the IP settings in the below 5 fields for your camera.

IP Address: Enter an IP address which you will use to access your camera and the web configuration page.

Subnet Mask: Enter the subnet mask to use for the LAN the camera is connected to.

Default Gateway: Enter the default gateway IP address configured for the LAN the camera is connected to.

Primary DNS: Enter the primary DNS address accessible from your LAN.

Secondary DNS: Enter a secondary DNS address.

Enable UPnP: Checking this box enables Universal Plug and Play which will allow windows to create an icon that represents the camera in the "My Network Places"

Enable UPnP Port Forwarding: Checking this box enables the settings below to assign both HTTP and RTSP ports to the camera. The default ports are 80 and 554 respectively.

External HTTP Port: Assign the HTTP port to be used for the camera. More than one camera on a network requires different HTTP ports for each camera to view them from the internet.

External RTSP Port: Assign the Real Time Streaming Protocol Port to the camera. This port is used by RTSP clients used for example on mobiles.

Enable PPPoE: If your camera is connected directly to a service provider using PPP checking this box sets up a PPP session with your network provider and uses the credentials below: If checked provide the user credentials such as username and password in the boxes below.

Port Settings

HTTP Port: Configure this with the HTTP Port to be used for viewing the camera over the internet.

RTSP Port: Configure this with the Real Time Streaming Protocol port used by an RTSP client to view the camera from for example, a mobile or smart phone.

User Authentication: Checking this box forces the user to supply their credentials upon every camera access.

Direct Video Stream Authentication

Enable: Once you enable this feature, you can view your camera from a direct link http://camera_IPaddress/tvaview.htm for Internet Explorer users and http://camera_IPaddress/tvview for non Internet Explorer users.

Click **Ok** to continue and save your settings.

Wireless Setup

Enable Wireless: Check this box to enable the wireless network connection mode of the camera

Site Survey: Click the pull-down menu to see the list of wireless networks available.

SSID: The SSID (Service Set Identifier) is the name assigned to the wireless network. Type the SSID of the Wireless LAN you want to connect to in the SSID field or use the drop-down menu to choose the SSID you want to connect the Camera to.


To refresh the list of available Wireless LAN's, click the **Site Survey** button.

Wireless Mode: Click on the drop-down menu to select either Infrastructure or adhoc wireless mode. Infrastructure allows direct connection to a wireless router or access point. Adhoc is for connecting with another wireless client that is in adhoc mode.

Channel: Use the drop-down menu to choose the channel used for communicating with your Wireless LAN. A "channel" is a range of frequencies used to communicate between the Camera and an Access Point in **Infrastructure** mode, or the Camera and PC/Notebook in **Ad-Hoc** mode.

Authentication Encryption: Click on the drop-down menu to select either disable or enable. Enable is automatically sets the authentication.

Key: Enter the exact security key (pass phrase) required for the authentication type.



The screenshot shows the 'Wireless Setup' window with the following fields and controls:

- wireless configuration** (Section Header)
- Enable Wireless:** A checkbox that is checked.
- Site Survey:** A pull-down menu showing '===SSID List===' and a 'Rescan' button.
- SSID:** A text field containing 'helloworld'.
- Wireless Mode:** A pull-down menu set to 'Infrastructure'.
- Channel:** A pull-down menu set to 'Auto'.
- Authentication:** A pull-down menu set to 'Open'.
- Encryption:** A pull-down menu set to 'Disable'.
- Key:** An empty text field.
- Buttons for 'Ok' and 'Cancel' at the bottom right.

Selecting a SSID from the Site Survey

When you click on the Scan button in the Wireless menu a list of networks is available in the pull-down list immediately below. Selecting one of these items automatically populates the **Wireless Mode**, **Channel**, **Authentication** and **Encryption** fields.

Once you select the SSID you must enter the security key if authentication is selected.

Dynamic Domain Name Service (DDNS)

DDNS is a method of keeping a domain name linked to a changing (dynamic) IP address. With most Cable and DSL connections, you are assigned a dynamic IP address and that address is used only for the duration of that specific connection. With the camera, you can setup your DDNS service and the camera will automatically update your DDNS server every time it receives a different IP address. Depending on the service, this update may take a few hours

Enable DDNS: Check this box enables the DDNS function of the camera.

Server Address: Use this box to enter in the DDNS server address or you can click on the drop-box to the right to select a server.


Host Name: Enter your assigned DDNS host name.

User Name: Enter your assigned user name.

Password/ Verify Password: Enter your assigned DDNS password twice for verification.

Timeout: This timeout is the number of hours to wait before the camera is disconnected from the assigned DDNS server.

Status: The status of the DDNS function; whether it is enabled or disabled.



The screenshot shows a 'Dynamic DNS' configuration window. It has a title bar 'Dynamic DNS' and a subtitle 'Dynamic DNS setting'. The window contains several fields: 'Enable DDNS' with a checkbox, 'Server Address' with a text box and a dropdown menu labeled '<< Select Dynamic DNS Server', 'Host Name' with a text box, 'User Name' with a text box, 'Password' with a text box, 'Verify Password' with a text box, 'Timeout' with a text box containing '576' and a label '(hours)', and 'Status' with a label 'Disable'. At the bottom right, there are 'Ok' and 'Cancel' buttons.

Video Audio

Video and Audio

Video Profile 1-4

Encode Type: Select one of **H264**, **JPEG**, or **MPEG4** encoding from the drop-down menu. Profile 4 is always set to MPEG4.

Resolution: Select the size of the desired screen viewing resolution.

FPS: Select the FPS (Frames per Second). 30 is the maximum (best quality).

bps: To control the amount of bandwidth that the camera uses select the BPS (Bits per Second). to fix the bandwidth rate. A higher bps provides a better image quality but requires more network bandwidth to transmit the image.

JPEG quality: If the encoding type selected above is JPEG, then in this menu the quality of the JPEG video can be selected.

RTSP URL: Use this setting to configure a suffix that is added to your cameras RTSP address. For example for a camera with IP set to 192.168.10.30 and RTSP set to 3gpp the entire URL to access this video profile from the camera is: **rtsp://192.168.10.30/3gpp**

Notes

The following Video Profiles are used for special purposes:

Video Profile 3 for viewing the camera in non-IE browsers. This profile is always configured as MJPEG.

Video Profile 4 is for viewing the camera over mobile devices. This profile is always set to use MPEG-4 encoding.

To obtain a better quality of video the frame size, frame rate and bit rates must be increased however this results in high bandwidth utilization. For a mobile phone it is suggested to use 5 fps and a bit rate of 20 kbps to obtain an excellent balance of picture quality versus bandwidth utilization.

Video and Audio

VIDEO PROFILE 1

Encode Type	Resolution	FPS	bps	JPEG Quality	RTSP URL
H264	704x480	30	2 Mbps	Good	play1.sdp

VIDEO PROFILE 2

Encode Type	Resolution	FPS	bps	JPEG Quality	RTSP URL
H264	352x240	10	256 kbps	Good	play2.sdp

VIDEO PROFILE 3

Encode Type	Resolution	FPS	bps	JPEG Quality	RTSP URL
JPEG	704x480	10	--	Good	play3.sdp

VIDEO PROFILE 4 for Mobile device only

Encode Type	Resolution	FPS	bps	JPEG Quality	RTSP URL
MPEG4	176x120	5	64 kbps	--	3gpp

Audio Setup

Enable Speaker: Check this box to enable the local external speaker on the camera. Using the microphone on your computer allows you to speak to anyone near the camera.

Audio Setup	
Enable Speaker	☒
Volume	50 ▾
Enable Microphone	☒
Volume	50 ▾

Volume: Adjusts the volume of the external speaker turned on above.

Enable Microphone: Check this to enable the camera's built-in microphone so that the you can receive audio along with the video from the camera.

Volume: Adjusts the volume of the audio coming from the microphone of the camera enabled above.

After making any changes, click the **Save Settings** button to save your changes, or click the **Don't Save Settings** button to discard your changes.

Click the **OK** button to save and activate your settings.

Image Setup

Brightness: Adjusts the level of the video brightness.

Saturation: Adjusts the saturation value. Increasing the value will increase the boldness of the colors.

Hue: Adjusts the video level of hue which will spectrally shift the colors up or down.

Contrast: Adjusts the level of contrast for the image. A higher value increases the definition of between dark and bright objects.

Sharpness: Adjusts the level of the image sharpness. Lowering the value will soften the image.

Frequency: Select either 50Hz or 60Hz to match the frequency of the monitor scan rate.

Flip: Check this to rotate the video 180 degrees on the vertical axis.

Mirror Check this to rotate the video 180 degrees on the horizontal axis. This is normally used when the camera is mounted upside down on a ceiling.

B/W: Check this to transmit the video in Black and White format.

Advance Image Settings

Auto Gain Control: When the level of input luminance is too dark, setting the AGC to high will automatically increase the image brightness.

Back Light Compensation: When the background of the input image is too bright, use the BLC function to make the objects in the image clearer.

2D Noise Reduction: When you increase the gain, noise in the image is also amplified. Use the 2D Noise Reduction to reduce the gain of the image noise.

3D Noise Reduction: Use this function to provide both temporal and spatial domain noise reduction. This type of noise reduction is very effective against random and Gaussian noise such as for example video images suffering from RF signal noise.

Preferred Mode:

- Select Aperture-preferred to have the camera image set based on the camera's aperture settings and the shutter speed selected automatically.
- Select Shutter-preferred to have the camera image settings be based on the selected shutter speed and the aperture set automatically.
- Select Manual to have the camera image settings based on manual setup of both aperture and shutter speed settings.

Iris Mode: In Aperture-preferred or Manual mode this field shows manual therefore the Iris Value field must be used to adjust the video image. In Shutter-preferred mode the Iris Mode changes to Auto and the Iris is adjusted automatically.

Iris Value: Use this pull-down menu to select an aperture setting in percent when the Auto Iris setting is set to Manual.

Sens Up: When the luminance level of the input image is too dark, the Sens Up function can compensate for this either automatically. Select Auto for Automatic Sens Up compensation and adjust the Sens Up compensation by using the Sens Up Value pull down menu item below. Select off to turn off this feature. Note the preferred-mode must be in Aperture-preferred to adjust Sens-up.

Sens Up Value: If Sens Up is set to Auto use this setting to adjust the value of the Sens Up compensation.

Image Setup

Live View

2010/07/18 08:38:53D TV-IP612P

Image Settings

Brightness	50	Saturation	50	Hue	50
Contrast	50	Sharpness	50	Frequency	50Hz
Flip	☐	Mirror	☐	B/W	☐

Advance Image Settings

Auto Gain Control	Low	Back Light Compensation	0
2D Noise Reduction	1	3D Noise Reduction	2
Preferred Mode	Aperture-preferred		
Auto Iris	Manual	Sens Up	Manual
Iris Value	85	Sens Up Value	x4
Shutter Mode	Auto	Shutter Value	1/120
White balance	Manual	RedOffset	29
		BlueOffset	41
Deinterlace	☒	Wide Dynamic Range	☐

Reset to Default

Shutter Mode (Shutter-preferred)

- Select Auto to have the camera shutter-speed be automatically set.
- Select Manual to adjust the shutter-speed of the camera using the Shutter Value settings in the below pull-down menu
- Select Anti-Flicker to remove the flicker caused by indoor lighting of the image.

Shutter Value: Select the desired shutter speed (in seconds) of the camera when the Shutter Mode setting is set to Manual.

White Balance: Adjust the level of White Balance so that white objects in the image appear with the correct white color.

- Select Manual to use the Red and Blue Offset adjustment settings to the right.
- Select Indoor to automatically adjust the White Balance for indoor imaging.
- Select Outdoor to automatically adjust the White Balance for outdoor imaging.

RedOffset: Adjust the Red Level percentage of the image when White Balance is set to Manual.

BlueOffset: Adjust the Blue Level percentage of the image when White Balance is set to Manual.

Deinterlace: Click this box to change the video format from interlaced to progressive.


Wide Dynamic Range: Click this box to adjust the camera settings automatically to increase the visibility and clarity of the brightest and darkest parts of the image.

Reset to Default: Click this button to reset to the factory default video image settings

ICR

The Infrared Cut Removeable (ICR) controls the operation of the ICR filter for changing light conditions such as from Day to Night. This section provides options to control the operation of the ICR filter.

Automatic: In automatic mode the camera will automatically enable or disable the ICR filter depending on the light conditions.



Day mode: If the camera is used only in a bright and well lit area, please select this option.

Night mode: If the camera is used only in a low-light and dimly lit area then select this option to increase the camera sensitivity by operating it in Black and White mode.

Scheduled Mode: This item allows you to manually program the time when the camera is in day mode using the **From (24hr)** and **to (24hr)** fields. Select scheduled mode and then enter the time you want to start day mode in the **From (24hr)** field and the time you want to end the day mode (start night mode) in the **to (field)**.

Action

Use this section to set up various actions to take based on input triggers preprogrammed.

Recording

Enable Recording: To enable the recording function check this box.

SD Card: Selecting this enables recording to a Micro SD memory card inserted in the camera.

Samba Network Drive: Select this item to record to a Samba network drive.

Samba Auth: From the drop down menu select the authentication type.

User Name: Input the Samba user name assigned.

Password/Confirm: Input the Samba password assigned twice to confirm it.

Server: Use this field to input the Samba drive URL or IP address.

Shared Folder: Input the name of the shared folder to use. (eg. TV-IP612P)

Test: Clicking **Test** verified that your settings are correct.

Samba Status: Check this item to see if the Samba drive is enabled and use to **Get Status** button to check it.

The screenshot shows the 'Recording' configuration page. It has a dark header with the title 'Recording'. Below the header, there's a section 'Recording' with a checkbox 'Enable recording'. Underneath is a 'Record to:' section with two options: 'SD Card' and 'Samba network drive'. The 'SD Card' option is currently selected, showing 'SD Card status : Disabled' and a 'Get status' button. The 'Samba network drive' option is also visible, showing 'Samba Auth' set to 'Anonymous', 'User name', 'Password', and 'Password confirm' fields, a 'Server' field, a 'Shared folder' field, and a 'Test' button. Below these is 'Samba status : Disabled' with another 'Get status' button. The bottom section is 'Recording Options', which includes 'Resolution' set to 'profile 1', 'Record file size' set to '1 minutes', 'Record until' set to '100 MB of free space is left (minimum is 100MB)', and a 'When storage is full' section with a radio button for 'Stop recording' and a checkbox for 'Overwrite older recordings'.

Recording Options

Resolution: Select the profile from the drop-down menu. Refer to the **Audio and Video** section for more information on profiles.

Record File Size: Select from 1 to 10 minutes in the pull-down menu.

Record until: Enter the minimum available hard drive space that must be left free and available for use when recording.

When Storage is Full: Use the **Stop Recording** setting to stop the recording when there is no longer any hard drive space. Otherwise use the **Overwrite older recordings** setting to record over old data when there is no longer any hard drive space.

Scheduling

Event Based: Click this setting to use event based triggering

Motion detection triggered recording: Select this option to start recording upon motion being detected.

Digital input 1 triggered recordings: Select this option to start recording upon Digital Input 1 sending an active signal.

Prerecord Seconds: This settings causes the camera to buffer a certain amount of video set in this field to save when motion is detected. The maximum amount of pre-detection video recorded is 15 seconds.

	Start	Hours	Minutes	End	Hours	Minutes
☒ Sun		00	:		24	:
☒ Mon		00	:		24	:
☒ Tue		00	:		24	:
☒ Wed		00	:		24	:
☒ Thu		00	:		24	:
☒ Fri		00	:		24	:
☒ Sat		00	:		24	:

Postrecord Seconds: Once event-base triggered recording begins and the event (for example motion detection) has ceased it will continue recording for the amount of time set here. A maximum post-event recording time of 15 seconds is settable.

Continuous: Selecting this option causes the camera to record video continuously. Only for use with Samba.

Scheduled: Selecting this option allows you to manually schedule when the recordings with begin and end each day.

Snapshot

Enable Snapshot: This option allows you to send an snapshot or still image from the camera attached to an E-mail or via an FTP server.

Trigger Event: These 2 options determine when to transfer an image via email or ftp. The image is sent either based on a Motion Detection trigger or a D/I Signal 1 going active option.

Continuous (FTP Only): This option causes snapshots to be sent non-stop. See the FTP Time Interval Setting.

Scheduled (FTP Only): This option allows you to schedule the specific period (start/end) in the time and day fields below when to send snapshots to an FTP server. See the FTP Time Interval Setting.

	Start	Hours	Minutes	End	Hours	Minutes
☒ Sun	Start	00	: 00	End	24	: 00
☒ Mon	Start	00	: 00	End	24	: 00
☒ Tue	Start	00	: 00	End	24	: 00
☒ Wed	Start	00	: 00	End	24	: 00
☒ Thu	Start	00	: 00	End	24	: 00
☒ Fri	Start	00	: 00	End	24	: 00
☒ Sat	Start	00	: 00	End	24	: 00

Email Settings

E-mail Address: Check this option to attach the image to an email sent to the user (email address) specified below.

User Name: The ISP username used. For example it could be [t_jones](mailto:t_jones@homeisp.com) or t_jones@homeisp.com.

Password: The account password for the username configured above.

SMTP Mail Server: The email server's hostname such as for example: smtp@t_jones.com.

Sender E-mail Address: The address used for the sent field of the e-mail with the image attached. This will receive deliver failure messages should there be problems with the email address specified previously for the destination. An example would be: t_jones@homeisp.com.

Recipient E-mail Address: The email address that will receive the images captured by the camera and attached to an email

Port: The port used by your SMTP service. Default port is 25.

FTP Settings

FTP Server: Check this option to send the image captured to a FTP server.

User Name: The account user name assigned and used for accessing the FTP server.

Password: The password used for the account username configured above.

Host Name: The FTP server's hostname or IP address. For example: ftp.trendnet.com.

Path: The FTP server file system path to the directory where the image is uploaded to. For example: \TV-IP612P

Filename Prefix: Use this field to configure a prefix added to the front of the filename used for each image.

Port: The FTP server port address normally set to the default of 21.

Interval: The interval time between images (snapshots) taken for the continuous or scheduled mode.

Passive Mode: Check this option if the FTP server configured is setup for passive mode clients. An FTP server setup in passive mode uses random ports for the file transfer.

Preset Position

Presets allow you to program a home camera view and programmable positions and save them for future viewing and recording.

Camera Control


Set as Home: Clicking this button sets the Home position to the current view.

Default Home: Clicking this button sets the home position of the camera view to the default factory programmed position.

Pan Speed: Use this drop-down configuration to set the camera panning speed from 1 to 10 where 10 is the fastest panning speed.

Tilt Speed: Use this drop-down configuration to set the camera tilt speed from 1 to 10 where 10 is the fastest tilt speed.

Current Postion: Type a name to use for the current camera view you would like to save as a preset position. Then click the **Add** button to save it.



Patrol Selection: This box shows the available Preset Locations saved which can be moved to the **Selected Locations** box below by highlighting them and clicking on the **Select** button.

Selected Locations: The preset locations in this box: determine the locations the camera will view when the Patrol button is pressed in the Live View window.

Pan/Patrol Speed: Set the speed from 1 to 5 with 5 being the fastest. This controls the speed of the camera movements when either the **Pan** or **Patrol** button is pressed in the **Live View** page.

Dwelling Time: The setting here determines how long the camera spends at the preset position. Enter from 1 to XXXX seconds.

Click the **Save** button to save and activate your settings.

Digital Output

The camera’s Digital I/O terminal block is the physical connection or interface for connecting external devices such as InfraRed Sensors, Alarm Relays, and Srents to the TV-IP612P/WN camera.

External Digital Input/Output Connectors

Digital I/O Terminal Block Description

The TV-IP612P/WN camera is equipped with a Input/Output terminal block that provides a single digital input and a relay to control external devices. Using Pins 1 and 2 allows you to connect a devices such as an external sensor (e.g. IR Sensor or Alarm Relays) so that the camera can monitor the voltage state where the initial state is set to “LOW” or deactivated. Pin 3 and 4 are connected to the camera’s output relay so that an external device can be controlled with “HIGH” activate or “LOW” deactivate signals (e.g. an external circuit to operate a Siren).

Using the I/O terminal block allows you to connect multiple external alarm devices that can then be used to trigger image recording or snapshots that can be stored or emailed to a remote location. Below is the diagram of the terminal block with the connector pin descriptions.

Input Output (I/O) Connector



PIN	Description
1	DI + INPUT (Maximum 50mA & 12VDC)
2	DI - INPUT (DI is initially set to low state)
3	SW_COMMON OUTPUT (Initial state is SW_OPEN) (SW_OPEN is closed when DO is HIGH)
4	SW_NOPEN OUTPUT (Maximum 1A & 24VDC or 0.5A &125VAC)

Trigger

Enable D/O Signal: Checking this box turns on the Digital Output to trigger external equipment such as alarm lights or sirens.

Trigger Event

Motion Detection:Checking the motion detection box causes the D/O pins to activate connected alarm devices upon motion being detected.

D/I Signal 1

Check this box to enable input on the D/I pins connected to a traditional alarm detection device.

Digital Output

Trigger

☐ Enable D/O Signal

Trigger Event

☐ Motion Detection

☐ D/I Signal 1

Ok

Cancel

Click the **OK** button to save and activate your settings.

Motion Detection

Live Video

Enable Video Motion: The camera can be setup to record whenever motion is detected in the camera's field of view and programmable predefined areas. Check this box to the motion detection function.


Sensitivity: This field allows you to specify how much movement will trigger motion detection in the trigger area. A higher sensitivity value means less movement is required. The trigger area is defined using the Drawing Mode check boxes below.

Drawing Mode:

Draw motion area:

Select to draw a motion area. Then use the mouse holding the left button down to drag a red squared area in the Live Video screen. The red grid that appears after using the mouse is the area selected to detect motion. In the Live View screen, when motion is detected in the red grid area then the motion detection symbol will blink according to the movements. See below note.

Erase motion area : Use this check box to be able to erase the Motion Detection area by dragging the mouse over it while holding the left button down.



Clear: Click the **Clear** button to remove all drawing areas.

Motion Detection Indicators



Note: The motion notification will continue to blink as long as motion is detected. If no additional motion is detected, it will return to its original state after eight seconds.


Click the **OK** button to save and activate your settings.

Tools

Backup and Restore

Save to Local Hard Drive: To save the configuration to a file click on the Save Configuration button.

Load From Local Hard Drive: If you need to load a saved configuration file into the camera click the **Browse** button and find and select the configuration file to be loaded. Then click the **Load Configuration** button to load the file which will apply the saved settings once loaded.



The screenshot shows a web interface titled "Backup and Restore" with a "system" header. It contains four main sections: "Save To Local Hard Drive" with a "Save Configuration" button; "Load From Local Hard Drive" with a "Browse..." button and a "Load Configuration" button; "Restore To Factory Defaults" with a "Restore Factory Defaults" button; and "Reboot Device" with a "Reboot Device" button.

Restore to Factory Defaults: To set the camera to the factory default settings click the **Restore Factory Defaults** button.

Reboot Device: To restart the camera, click the **Reboot Device** button.


Firmware Upgrade

Please check the TRENDnet Support webpage to check if any new firmware version is available for your camera. The current firmware utilized by the camera is listed in the Firmware Upgrade page in the Firmware Information section.

Firmware upgrade

Step 1. Once you have a new firmware version available for upload click on the **Browse** button to select the file from your files system.

Step 2. With the firmware file selected click on the **Upload** button which will begin the firmware upgrade.



The screenshot shows a web interface titled "Firmware Upgrade" with a "Firmware Information" header. It displays two rows of information: "Current Firmware Version: 1.00, 4424" and "Current Product Name: TV-IP612WN". Below this is a "firmware upgrade" section with a "File Path:" label, a "Browse..." button, and an "Upload" button.

Note: Do not turn off power to the camera while the firmware upgrade is in process.

Device Info

Device Info

Detailed information about your camera' system and network settings can be found on this page

Device Info	
Information	
Camera Name	TV-IP612WN
Time & Date	Mon Jul 5 16:16:37 2010
Firmware Version	1.00, 4424
MAC Address	00:01:A6:32:B7:54
IP Address	192.168.10.30
IP Subnet Mask	255.255.255.0
Default Gateway	192.168.10.30
Primary DNS	
Secondary DNS	
PPPoE	Disable
DDNS	Disable

Log


Logs recorded by the camera can be viewed on this page. Click the **Download** button at the bottom of the page to save the log file to a text file on your hard drive.

Log	
current log	
2010-01-04 05:05:41	System is booted up.
2010-01-04 05:06:17	admin is starting to watch video streaming by http
2010-01-04 05:08:32	admin is starting to watch video streaming by http
2010-01-04 05:08:35	admin is starting to watch video streaming by http
2010-01-04 13:32:59	System is booted up.
2010-01-04 13:38:50	System is booted up.
2010-01-06 12:14:19	System is booted up.
2010-07-07 08:10:39	System is booted up.
2010-07-07 08:11:05	admin is starting to watch video streaming by http
2010-07-07 08:11:29	admin is starting to watch video streaming by http
2010-07-07 08:11:45	admin is starting to watch video streaming by http
2010-07-07 08:12:20	admin is starting to watch video streaming by http

Viewing Video

The TV-IP612P /TV-IP612WN camera allows you to view video images using in your web browser. Click the **Live View** button on the screen to access the video images.

Note: If you **Left Click** anywhere in the image this will cause the camera to position the center of the image over the point you clicked.



Camera Name and Date/Time: The camera name and the correct current date/time will be displayed when the related information has been entered in the Configuration section of the Web Configuration Utility.

Controlling the Camera

You can control the Camera's viewing angle using the control buttons on the left-hand side of the viewing window. You can control video modes, audio modes, recording settings and digital output using the control panel underneath the image (described on the next page).

Outer Ring: Click on the arrows on the outer ring to move the camera. Click the right arrow to move the camera to the right, the up arrow to move the camera up, etc.

Home: Click the **Home** icon to move the camera to its home position.

Inner Ring (Optical Zoom): Click the left button to zoom in and click the right button to zoom out

Auto Focus: Click to allow the camera to focus automatically (recommended).

Manual Focus: Click to manually focus the camera. Use the - and + buttons to focus in and out.

Pan: Continuously pans the camera one full cycle

Patrol: Enables the Auto Patrol feature. Please refer to **page 47** to configure preset locations.

Stop: Stops movement of the camera during pan or patrol


Go To: Select a preset position from the drop-down menu to move the camera to.

Pan Speed: Select the speed at which the camera will pan (1-10, 10 = fastest).

Tilt Speed: Select the speed at which the camera will tilt (1-10, 10 = fastest).

SD Status: Displays the status of your Micro SD memory card. If you do not have a card inserted into the camera, it will display as **Invalid**.





1. **Video 1** - Click this button to view the image using **Video Profile 1** settings. Go to the **Setup** section **Video/Audio – Video and Audio** to change the Profile settings.
2. **Video 2** - Click this button to view the image using **Video Profile 2** settings. Go to the **Setup** section **Video/Audio – Video and Audio** to change the Profile settings.
3. **Video 3** - Click this button to view the image using **Video Profile 3** settings. Go to the **Setup** section **Video/Audio – Video and Audio** to change the Profile settings.
4. **Video 4** - Click this button to view the image using **Video Profile 4** settings. Go to the **Setup** section **Video/Audio – Video and Audio** to change the Profile settings.
5. **Full Screen** – Clicking this button expands the camera view to full screen. Pressing **ESC** on the keyboard return the view to the standard view.
6. **Snapshot** – To record a still image of the current camera view click this button. The image appears in a new browser where you can save the file from.
7. **Recording** – Clicking this started the video recording function. Clicking again stops the recording.
8. **Set Storage Folder** – Clicking this icon allows you to set the folder on the file system to store video and snapshots.
9. **Listen** – Click this to turn on or off the camera's microphone. The microphone in the camera allows you to hear any audio in the vicinity of the viewing area. The default is on.
10. **Talk** – Clicking this causes the audio from a microphone or other source at the computer to be fed to the speaker output (A/V jack) at the camera. Use this to speak to anyone in vicinity of the camera
11. **Start Digital Output** – Click this on activates the digital output signal
12. **Digital Zoom/Pan &Tilt** – Changes the pointer over the image to a magnifying glass when the icon is highlighted yellow. Clicking the pointer causes the image to be zoomed with the center at the click point. Clicking the icon again to turn of the yellow highlight changes the pointer to a Pan and Tilt function only when the pointer is clicked anywhere on the image.


IPView Pro 2.0

This section describes the how to setup a camera using the IPView Pro 2.0 camera monitoring software. To install IPView Pro 2.0 on a system running Windows, launch the IPView Pro 2.0 installation software on the installation CD-ROM and follow the setup instructions. Once the software is installed, the IP Cam Center camera monitoring utility is ready for use. Add up to 32 network cameras to monitor using the software. Additional software, IPCam Player software is also installed. The IPCam Player is used for playing recorded video from cameras that have been configured to save recorded files.

Launching IPView Pro 2.0 for the first time

To launch IPView Pro 2.0 double click on the IPView Pro 2.0 icon on your desktop or go to **Start > Programs > TRENDnet > IPView Pro 2.0 > IPView Pro 2.0**. If this is the first time using the software, the menu that appears is the **Add camera** menu. To add your IP camera:

- Search for the IP camera on the local area network (click on refresh) or
- Import an existing configuration file




Add a camera for monitoring

The Add camera menu is presented the first time the IPView Pro 2.0 software is launched. This menu is used to add cameras to the user interface for monitoring. After the first time running the software, this menu can be accessed at anytime from the Configuration menus. The Configuration menus are described in a later section of this chapter. Notice that the IPView Pro 2.0 software has automatically detected eligible cameras running on the network.

To add a camera to the IPCam user interface, follow these instructions:

1. Check the list of cameras detected by the software. If the camera you want to add does not appear on the list, click the **Refresh** button to conduct another search. If it still does not appear, check the IP address of the camera and click on the Input the location of camera menu tab and skip ahead to step 2.1.



2. Select the camera to add from the list, enter the administrator's user name (ID) and password, a preview of the live video display will appear. Click the OK, add this camera button, a confirmation message informs when the camera is connected and added to the IPView Pro 2.0 monitoring group. Repeat this procedure for all the cameras being added. Click the Exit button after all the cameras have been added.

If the camera does not appear listed, click the **Input the location of camera** tab above the list to view a new menu. Enter the IP address or the URL (for example, *ipcam.ddns.org*) of the camera being added, type the user name and password and click the **Preview** to verify that a link can be established. The live video of the camera should appear in the **Live preview** display. If a link cannot be established, run the Setup Wizard software for the camera and verify the correct IP address. Click **Exit** to return to the main **Add camera menu**.

Add camera for monitoring

Select a camera in LAN | **Input the location of camera**

Type the IP address of the camera

Location:(Ex:'192.168.0.1' or 'ipcam.ddns.org')

192.168.1.54

Preview

Port(1-65535. Default is 80) 80

After input the location and port number of the camera. Click button "Preview" with correct username and password to see its live video. To Add this camera, please click button "Ok, add this camera" below.

Enter user name and password for camera being added

Live preview of 192.168.1.54

2010/08/06 15:54:02 V-16612

Username admin

Password

Camera is connected!


The camera has been added:
192.168.1.54

Ok, add this camera Exit

- Once the cameras have been added, they are ready to be used in the main IPView Pro 2.0 user interface. Close the Add camera menu (click **Exit**) to go to the main user interface. See below for a description.

IPView Pro 2.0 User Interface

Below is a general description of the user interface.




NO.	Item	Description
1	Live video display area	Display area for single or multiple cameras of live video. Right click on any display area to view a list of quick configure options for that camera including the "Replace camera content ..." option used to change the order of the live video displays for multiple camera views.
2	Minimize and Exit	Use to minimize IPView Pro 2.0 interface or exit the program , a confirmation is required to exit.
3	Pan and Tilt control (cameras using RS-485 Pan / Tilt device only)	Click directional arrows to move camera in that direction within the limits of the pan and tilt range. The + in the center of the control is used to return to the home or center view as configured for the camera.
4	Zoom	Click the + or – buttons below the Pan and Tilt Control Warning: If the camera does not focus go to the Live View portion of the Browser and make sure that auto focus is checked (i.e. Not manual focus). **the pan/tilt speed control above Zoom can also control the zoom in/out distance**
5	Snapshot, recording and audio controls	See below for detailed information.

6	Live video display controls	See below for detailed information.
7	Camera configuration menu	See below for detailed information.
8	Camera status	Use to quickly assess the status of operating cameras. Click on box to select camera display. The status indicators for each camera display recording, motion detection and GP input status.
9	Camera information	Displays basic information on selected camera.

Display Controls

The primary display and IPView Pro 2.0 control icons are described in detail below. When there are more than one camera displays viewed, one of the displays can be selected for management or additional changes. Simply left click on any display to select it. Notice the border around the display is bright aqua blue, indicating the “selected” status. For example, to go to a single screen display for any one camera, select the camera and click on the single screen display.




Snapshot, recording and audio controls


The still photo camera icon is used to take a snapshot of the selected live video display. The video camera icon is used to begin video recording of the selected live video display. Snapshot and videos files are stored in a default folder on the administrator’s system, or in a folder designated by the administrator.

The audio controls are represented by a microphone icon to activate the internal mic or the auxiliary audio input (if present), and a speaker icon for the audio output (remote speakers, if present).

Notice that when these functions are activated, the color of the icon changes from white to yellow.




Audio and video controls - inactive



Audio and video controls - activated

Live video display controls

Use the video display controls to change the view of the live video display. This is useful for multiple camera application.



The interface shows a vertical toolbar on the left with icons for navigation, display layout, recording, playback, and settings. At the top are two circular arrows for cycling through cameras. To the right of the toolbar is a grid of camera display thumbnails.

Click the arrows to manually cycle through the active camera's live displays when using a single camera display screen.

Click multi-screen display icons to change the number of camera's displayed at one time.
To change the order in which the camera displays appear in the interface, move the cursor over a display you want to change and right click. A dialog appears (see example below). The top most option in the dialog allows the user to *Replace content by ...* followed by a list of connected camera IP addresses (or URL locations). Select the camera display you want to occupy the position the cursor is placed over. The display position will then be swapped with the chosen camera.

Switch to **full screen** view of selected display screen.

Click to **record all** active cameras.

Click to **add** or **configure** cameras. See details below.

Click to automatically **cycle through** the active camera displays.

Launch **IPCamPlayer** to view stored video files.

Camera configuration with IPView Pro 2.0

Access the camera configuration menus by clicking on the gear icon at the bottom of the right hand panel of the IPView Pro 2.0 user interface. Configuration options include adding and deleting cameras from the display view, configuration of motion detection and digital input with schedules, recording options, email alerts and other network settings.

Adding a Camera – Camera management

The procedure to add a camera after the initial launch of the software is very similar to the procedure used during the first setup. Follow the instructions below to add cameras.

To add a camera:

1. Click the Configuration icon to view the Camera Setup menu. The top most tab of the menu is the Camera Management tab. A list of active cameras appears on the left half of the menu. Select the camera to be added from the list. **Click the Add Camera by IP Address** to find the specified IP address or network URL of the camera you want to add.

Add camera for monitoring

Select a camera in LAN | Input the location of camera

Location:(Ex-'192.168.0.1' or 'ipcam.ddns.org')

192.168.1.54 Preview

Port(1-65535. Default is 80) 80

After input the location and port number of the camera. Click button "Preview" with correct username and password to see its live video. To Add this camera, please click button "Ok, add this camera" below.

Live preview of 192.168.1.54

2015/08/06 15:54:02 V-T612P

Username admin


Password

Camera is connected!

The camera has been added:
192.168.1.54

Ok, add this camera Exit

2. Select the camera to add from the list, enter the administrator's user name (**ID:**) and password, a preview of the live video display will appear. Click the **OK, add this camera** button, a confirmation message informs when the camera is connected and added to the IPView Pro 2.0 monitoring group. Repeat this procedure for all the cameras being added. Click the **Exit** button after all the cameras have been added.



- The camera added now appears in the Camera List. To launch the web manager for the newly added camera or any camera in the active camera list, select it and click the **Browse Selected Camera** button.

Removing a Camera

To remove the camera from the list of active:

1. Select the camera you want to remove.
2. Click **Delete Selected Camera**.


NOTE: Any camera display can be removed from the main IPView Pro 2.0 user interface by right-clicking on the display screen for the camera and selecting the **Remove this Camera** option.

Launch Web Manager for Selected Camera

To launch the web-based IP Camera manager for any active camera in the list, simply select it and click the **Browse Selected Camera** button.

Schedule Recording with IPView Pro 2.0


Use the **Monitoring Settings** menu to create schedules for recording and apply the schedules to any camera. Click the **Monitoring Settings** tab to view the **Schedule Recording** menu (the first menu viewed in the Camera Settings menu tab).



To apply an existing schedule template, click the **Enable schedule recording** checkbox then click the **Select** button and choose a schedule from the list of previously created schedule templates by checking its checkbox and click the OK button. If a new schedule is needed it can be created by clicking **Select button** and then the **Edit profiles** button in the **Select schedule profiles** dialog box.


Create Schedule Templates

To make a new schedule template, click the **Edit Template** button to view the Select schedule profiles dialog box. Use this new dialog box to create new schedules for recording.




Setup Motion Detection and Digital Input with IPView Pro 2.0

The Camera Settings menus include **Motion Detection** setup and **Digital Input** control. Each menu has the schedule option to apply a schedule for the action taken or always take the specified action.



For Motion Detection, use the *Config motion detection area* menu to create the area to which it is applicable. Click the **Config motion detection area** button in the Motion Detection setup menu to view the menu in a new pop up window. High sensitivity rate leads to



The sensitivity value is based on a scale. The lower the sensitivity rating the more motion will be required to trigger an event. Using too high a sensitivity rating may trigger false events.

IPView Pro 2.0 Recording Options

The Recording Options configured in the IPView Pro 2.0 help to conserve and manage allowed memory storage (disk space) and for video file management. Recorded files can be limited by time elapsed or by size. Use the select storage folder to choose an alternative destination for stored video files. Storage limits can be set for each camera by time elapsed or hard disk space allowed. A limit can also be placed for the system and all cameras used in IPView Pro 2.0.

Configuration

Camera management | Monitoring settings | **Recording options** | Other options

Recording configuration


Folder
Set the folder for recording and snapshot.
documents and Settings\04144\My Documents

☒ **Reserved space**
Set the reserved HDD space for system.
500 MB

☐ **Quota**
Set the quota for each camera, you can select by space or by time.
☒ By space 500 (MB)
☐ By time 1 (Days)

Disk space usage information

Disk C:



Total	39079 MB
Used	17048 MB
Available:	22031 MB
Reserved	500 MB
Current camera number	1
Total quota:	500 MB
Free	21031 MB

Recording file splitting
Set the length of the recording file. You can be set by recording time or by file size.
☒ Time interval ☐ Size interval 60 Seconds (7200 seconds at most)

IPView Pro 2.0 Miscellaneous Options

The Other Options available for configuration include Proxy server setup, email notification, scan interval and alert type settings.


The screenshot shows the 'Configuration' window for IPView Pro 2.0, specifically the 'Other options' tab. The window has a title bar with a close button. Below the title bar is a tabbed interface with four tabs: 'Camera management', 'Monitoring settings', 'Recording options', and 'Other options'. The 'Other options' tab is selected. The main area is divided into several sections:

- Proxy settings:** Contains a checkbox for 'Proxy'. If checked, there are text boxes for 'Address' and 'Port' (set to 1). Below it is a checkbox for 'Bypass proxy server for local network address'.
- Time interval of scan:** A dropdown menu set to '5' with the unit 'Seconds'.
- Sound alarm settings:** Contains three sections:
 - Motion detection alarm sound:** A text box with the path 'C:\Program Files\TRENDnet\IPView Pro 2.0\eventn...' and a browse button.
 - Digital input alarm sound:** A text box with the same path and a browse button.
 - Camera disconnected alarm sound:** A checked checkbox followed by a text box with the same path and a browse button.
- E-mail sender settings:** Contains text boxes for 'Sender E-mail address', 'Subject title', and 'SMTP mail server'. A 'Port' dropdown is set to '25' with a range '(range :1~65535)'. There is an 'SSL' checkbox and text boxes for 'Username' and 'Password'. A 'Test' button is at the bottom right of this section.
- System settings:** Contains two checkboxes:
 - ☐ Automatically launch this program when system starts.
 - ☐ Resume Manual Recording state on application start up.

At the bottom right of the window are 'About', 'OK', and 'Cancel' buttons.

Playing Video Files on a Computer

IPCamPlayer software is installed on the monitoring station or administrator's system along with the IPView Pro 2.0 monitoring software. Use it to playback and manage recorded video from the cameras added to the IPView Pro 2.0 group. In order to use the software however, it is necessary to first install the **ffdshow** package of codecs used for media files. There is an ffdshow installation file on the CD shipped with the camera. Install ffdshow before using the IPCamPlayer. For information on installation and use of ffdshow, see the **ffdshow** section at the end of this chapter.



The IPCamPlayer can be launched directly from the IPCamCenter or from the Programs menu. To launch the program from the IPView Pro 2.0 interface, click the movie icon on the control panel of the main IPView Pro 2.0 interface to launch IPCamPlayer.



NOTE: Install the **ffdshow** package of video codecs from the installation CD before using the IPCamPlayer.

Load Saved Video Files

Each camera has a file created automatically for storing video files. These files are normally located in the My Documents folder in Windows. The file folders are named according to the IP address and camera model. For example, 192.168.10.30_TV-IP612P/W is the name of the file folder for the TV-IP612P/W using the default (non-DHCP) IP address.

IPCamPlayer User Interface



NO.	Item	Description
1	File list	Video files added to the list are viewed in the order listed.
2	View Screen	Video files in the list are played here. The progress bar and starting time of the video clip appears beneath the view screen.
3	Add / Delete files from list	Use the Search Files button to add recorded video files. A new menu pops up that is used to find and add files to the list. (See description on next page)
4	Playback controls	Standard video playback controls for Stop , Play / Pause , go to next file (>>) or go to previous file (<<) Faster and Slower to control speed of playback. Playback can be slowed to as much as 1/8 normal speed or speeded up to as fast as 8 times the normal speed. The vertical slider control is used for audio volume control.

To view recorded video files in the IPCamPlayer, it is first necessary to locate and select the files to be viewed and add them to the list. Click the **Search Files** button in the IPCamPlayer main interface and a new menu appears.

In the new menu, use the **Select Camera** pull-down menu to choose the video file folder of the camera to be reviewed. Use the **Search Time** menu to narrow the search to a specific time and date. Finally, the **Event** selection menu is used to further narrow the scope of the file search for videos triggered by **Motion Detection** or a **Digital Input** device. When the search criteria have been defined, click the **Search** button to place qualified files in the Search list.

IP Address	Camera Name	Date & Time
☒ 192.168.1.67	TV-IP512P	20090227120225
☒ 192.168.1.67	TV-IP512P	20090227120326
☒ 192.168.1.67	TV-IP512P	20090227120524
☒ 192.168.1.71	TV-IP512WN	20090227120225
☒ 192.168.1.71	TV-IP512WN	20090227120326
☒ 192.168.1.71	TV-IP512WN	20090227120523
☒ 192.168.1.73	TV-IP600W	20090227120225
☒ 192.168.1.73	TV-IP600W	20090227120326
☒ 192.168.1.73	TV-IP600W	20090227120445
☒ 192.168.1.73	TV-IP600W	20090227120604
☒ 192.168.1.76	TV-IP600	20090227120225
☒ 192.168.1.76	TV-IP600	20090227120226
☒ 192.168.1.76	TV-IP600	20090227120326
☒ 192.168.1.76	TV-IP600	20090227120456

Select Camera :

Search All Camera

Select Time :

From : 2009/02/24 12:08:01

To : 2009/02/27 12:08:01

Event :

☐ Motion Detection

☐ Digital Input

Search OK

Add Select All Clear All

TRENDNET

Choose the files to be added to the view file list by check marking the individual files or click the **Select All** button to check mark all files in the Search list, click **Add** to place the check marked files on the list of files for viewing.

After the files to be viewed have been chosen, click the **OK** button.

Play Video Files

Now that the recorded video files have been selected and placed on the file list, they can be played and reviewed in the IPCamPlayer. Use the standard playback controls to play video files at normal speed or slowed down, paused, speeded up etc. Use the mouse and left click to grab the playback sliding progress indicator to move back and forth through the video.

ffdshow


The ffdshow software is used for audio and video encoding and decoding, especially for MPEG-4 formats. It is free software used on Windows systems and enables the user to tweak media playback and select specific codecs and formats. For use with the IPCamPlayer, the default settings used for ffdshow installation are all that is needed. Expert users can change audio and video codecs as desired with one of the three ffdshow configuration utilities installed along with the codecs. The configuration utilities can be accessed after installation from the ffdshow folder in the Programs folder (Start > Programs > ffdshow >[configuration utility]).

Install ffdshow

1. Insert the CD-ROM into the CD-ROM drive to initiate the auto-run program. The menu screen will appear as below:




2. Click the **ffdshow** install link, and select the desired language in the pop-up dialog window.




3. The InstallShield Wizard will appear, click **Next** in the welcome screen.




4. Accept the default location (Windows Programs folder) on the system for placement or **Browse** to choose an alternative, Click **Next** to continue.




5. Click to check the components that will be installed. For IPCamPlayer it is only necessary to use the default components already selected. Click **Next** to continue.




6. Accept the default destination folder (ffdshow) or **Browse** to choose an alternative, Click **Next** to continue.




7. Click to check the additional tasks that will be installed. For IPCamPlayer it is only necessary to use the default formats already selected. Click **Next** to continue.




8. Click to check the video applications that use ffdshow. For IPCamPlayer it is only necessary to use the default applications already selected. Click **Next** to continue.




9. Click to check the audio applications that use ffdshow. For IPCamPlayer it is only necessary to use the default applications already selected. Click **Next** to continue.



10. Choose a speaker setup or choose Disable mixer if unsure. The audio function will work regardless of what speaker setup is chosen. Usually it will choose the default arrangement used on system on which it is being installed. Click **Next** to continue.



11. Review the information and click **Install** if satisfied that it is correct to install the necessary codecs. The installation will take a few seconds.



12. If desired, any of the three configuration utilities included with the ffdshow installation can be launched by checking the appropriate box. Click **Finish** to complete the installation.



NOTE: To download the latest copy of ffdshow please check the ffdshow website <http://ffdshow.en.softonic.com/>

Appendix

A. Frequently Asked Questions

Internet Camera Features

- Q:** What is an Internet Camera?
- A:** An Internet Camera is a stand-alone system connecting directly to an Ethernet or Fast Ethernet network and supported by the wireless transmission based on the IEEE 802.11b/g/n standard. It is different from the conventional PC camera, the camera is based on an all-in-one system with built-in CPU and web-based solutions providing a low cost solution that can transmit high quality video images for monitoring. The Camera can be managed remotely, accessed and controlled from any PC/Notebook over the Intranet or Internet via a web browser.
- Q:** What is the maximum number of users that are allowed to access the Camera simultaneously?
- A:** The maximum number of users that can log onto the Camera at the same time is 20. Please keep in mind the overall performance of the transmission speed will slow down when many users are logged on at the same time.
- Q:** What algorithm is used to compress the digital image?
- A:** The Camera utilizes JPEG image compression technology, providing a high quality image for users. JPEG has been adopted as it is a standard for image compression and can be applied to a variety of web browsers and software applications, avoiding the need to install additional application software.
- Q:** Can I change the wireless antenna attached to the Camera?
- A:** The wireless antenna can be changed for a variety of reasons, such as extending the wireless transmission range. However, please consult an authorized distributor before attempting this as the connectors must use an SMA connector type.
- Q:** What is the wireless transmission range for the Camera?
- A:** Generally the wireless signal can reach up to 100 meters indoors and up to 300 meters outdoors. The range is limited by the number of walls, ceilings or other objects that the wireless signals must pass through. Typical ranges vary depending on the types of materials and background Radio Frequency (RF) noise in your home or business and the configuration setting of your network environment.

Internet Camera Installation


- Q:** Can the Internet Camera be used outdoors?
- A:** The Camera is not water-proof and it is not recommended to use it outdoors. But you can use our Outdoor Internet Camera Enclosure TV-H500 or the one with Heater and Fan model TV-H510 to install the camera outdoor.
- Q:** What type of network cabling is required for the Camera?
- A:** The Camera uses Category 5 UTP cable allowing 10 Base-T and 100 Base-TX networking.
- Q:** Can the Camera be setup as a PC-cam on a computer?
- A:** No, the Camera is an Internet Camera used only on Ethernet and Fast Ethernet networks and supports wireless connections.
- Q:** Can the Camera be connected to the network if the LAN only consists of private IP addresses?
- A:** The Camera can be connected to a LAN with private IP addresses.
- Q:** Can the Camera be installed and work if a firewall exists on the network?
- A:** If a firewall exists on the network, port 80 should be open for ordinary data communication. However, since the Camera transmits image data, the default port 8481 is also required. Therefore, it is necessary to open 8481 on your firewall so that remote users can access the Camera.

B. PING your IP Address


The PING (Packet Internet Groper) command can determine whether a specific IP address is accessible by sending a packet to the specific address and waiting for a reply. It can also be a useful tool in confirming whether an IP address conflicts with the Camera's on the network.

To find out if the Camera conflicts with another IP address on the network follow the steps below:


1. Disconnect the Camera from the network.
2. Open a new DOS Window, by clicking **Start > Run** as shown below:



3. Type **cmd** in the **Run** window:



4. Type ping x.x.x.x, where x.x.x.x is the IP address of the Camera, as shown below:



```
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>ping 10.73.87.99

Pinging 10.73.87.99 with 32 bytes of data:

Reply from 10.73.87.99: bytes=32 time<1ms TTL=255
Reply from 10.73.87.99: bytes=32 time<1ms TTL=255
Reply from 10.73.87.99: bytes=32 time<1ms TTL=255
Reply from 10.73.87.99: bytes=32 time<1ms TTL=255

Ping statistics for 10.73.87.99:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\Documents and Settings\user>
```

Reply messages indicate that there is another device on the network, as indicated in the above window.


C. Troubleshooting

Q: I cannot access the Camera from a web browser?


A1: The possible cause might be that the IP address of the Camera is already being used by another device. To correct the possible problem, you need to disconnect the Camera from the network first. Then run the PING utility (follow the instructions in Appendix B – PING your IP Address for more information).

A2: Another possible reason is the IP Address is located on a different subnet. To identify if this is the problem, run the PING utility (follow the instructions in Appendix B – PING your IP Address for more information). If the utility returns "no reply" message or similar, it is possible that your Camera is on a different subnet from your computer. Carry out the following:


A2.1: Open the Control Panel by clicking **Start > Control Panel** as shown below:




A2.2: Click the Network Connections icon as shown below:




A2.3: Double-click the network adaptor that is connected to your Camera:




Select TCP/IP from the “Network” dialog box and from the TCP/IP Properties:



Click the **Properties** button.



Double-click the **Internet Protocol (TCP/IP)** item and check that the first 3 bytes of your computer's IP address correspond with the first 3 bytes of the Camera's.



If the Camera is situated on a different subnet than your workstation, you will not be able to configure the Camera. Therefore, you must connect to the Camera from a PC on the same subnet to configure the Camera settings.

- A3:** The wireless connection might be faulty. If your Camera is operating in Ad-Hoc mode make sure the Camera wireless channel and SSID are set to match the PC/Notebook and the Camera must match with the Access Point's SSID.
- Q:** Why does the Camera work locally but not externally?
- A1:** The Camera's connection might be being blocked by a Firewall. Please check with your System Administrator to see if your Firewall allows access to the Camera.
- A2:** This could be caused by the Default Router setting. Double-check that the Camera's Default Router setting is correct.
- Q:** Why do a series of broad vertical white lines appear throughout the image?
- A:** A likely issue is that the CMOS sensor has become overloaded when the light source is too bright, such as direct exposure to sunlight or halogen light. You will need to reposition the Camera into a more shaded area immediately to avoid damaging the CMOS sensor.
- Q:** Noisy images occur, how can I resolve the problem?
- A1:** The video images might be noisy if the Camera is used in a very low light environment. To solve this issue you will need to increase the level of light in the Camera's location.
- A2:** There could be interference from other wireless devices on the network that are affecting the wireless transmission.
- Q:** There is poor image quality, how can I improve the image?
- A1:** A probable cause might be an incorrect property display configuration for your desktop. To check if this is the cause, open the Display Properties on your desktop and configure your display to show at least 65,000 colors, for example at least 16-bit.
- A2:** The configuration on the Camera image display is incorrect. Through the Web Configuration Image section you will need to adjust the image related parameters to improve the image, such as the brightness, contrast, hue and light frequency controls. Please refer to the Web Configuration section for more detailed information.
- Q:** There are no images available through the Web Browser?
- A:** ActiveX might be disabled. If you are viewing the images using Internet Explorer make sure ActiveX has been enabled in the **Internet Options** menu. Alternatively, you can use the Java Applet for viewing the required images.

D. Time Zone Table

Time Zone	Location/Description
(GMT - 12:00)	Enjwetok, Kwajalein
(GMT - 11:00)	Midway Island, Samoa
(GMT - 10:00)	Hawaii
(GMT - 09:00)	Alaska
(GMT - 08:00)	Pacific Time (US & Canada; Tijuana)
(GMT - 07:00)	Arizona
(GMT - 07:00)	Mountain Time (US & Canada)
(GMT - 06:00)	Central Time (US & Canada)
(GMT - 06:00)	Mexico City, Tegucigalpa
(GMT - 06:00)	Saskatchewan
(GMT - 05:00)	Bogota, Lima, Quito
(GMT - 05:00)	Eastern Time (US & Canada)
(GMT - 05:00)	Indiana (East)
(GMT - 04:00)	Atlantic Time (Canada)
(GMT - 04:00)	Caracas, La Paz
(GMT - 04:00)	Santiago
(GMT - 03:30)	Newfoundland
(GMT - 03:00)	Brasilia
(GMT - 03:00)	Buenos Aires, Georgetown
(GMT - 02:00)	Mid-Atlantic
(GMT - 01:00)	Azores, Cape Verde Islands
(GMT)	Casablanca, Monrovia
(GMT)	Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London
(GMT + 01:00)	Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna
(GMT + 01:00)	Belgrade, Bratislava, Budapest, Ljubljana, Prague

Time Zone	Location/Description
(GMT + 01:00)	Brussels, Copenhagen, Madrid, Paris, Vilnius
(GMT + 01:00)	Sarajevo, Skopje, Sofija, Warsaw, Zagreb
(GMT + 02:00)	Athens, Istanbul, Minsk
(GMT + 02:00)	Bucharest
(GMT + 02:00)	Cairo
(GMT + 02:00)	Harare, Pretoria
(GMT + 02:00)	Helsinki, Riga, Tallinn
(GMT + 02:00)	Jerusalem
(GMT + 03:00)	Baghdad, Kuwait, Riyadh
(GMT + 03:00)	Moscow, St. Petersburg, Volgograd
(GMT + 03:00)	Nairobi
(GMT + 03:30)	Tehran
(GMT + 04:00)	Abu Dhabi, Muscat
(GMT + 04:00)	Baku, Tbilisi
(GMT + 04:30)	Kabul
(GMT + 05:00)	Ekaterinburg
(GMT + 05:00)	Islamabad, Karachi, Tashkent
(GMT + 05:30)	Bombay, Calcutta, Madras, New Delhi
(GMT + 06:00)	Astana, Almaty, Dhaka
(GMT + 06:00)	Colombo
(GMT + 07:00)	Bangkok, Hanoi, Jakarta
(GMT + 08:00)	Beijing, Chongqing, Hong Kong, Urumqi
(GMT + 08:00)	Perth
(GMT + 08:00)	Singapore
(GMT + 08:00)	Taipei
(GMT + 09:00)	Osaka, Sapporo, Tokyo

Time Zone	Location/Description
(GMT + 09:00)	Seoul
(GMT + 09:00)	Yakutsk
(GMT + 09:30)	Adelaide
(GMT + 09:30)	Darwin
(GMT + 10:00)	Brisbane
(GMT + 10:00)	Canberra, Melbourne, Sydney
(GMT + 10:00)	Guam, Port Moresby
(GMT + 10:00)	Hobart
(GMT + 10:00)	Vladivostok
(GMT + 11:00)	Magadan, Solomon Islands, New Caledonia
(GMT + 12:00)	Auckland, Wellington
(GMT + 12:00)	Fiji, Kamchatka, Marshall Islands

E. Technical Specifications

Camera	
General	Sensor: 1/4" CCD Sensor Focal Length: f(wide) 3.8mm to f(tele) 38.0mm F/No: F(wide)=1.8 , F(tele) = 2.8 LENS: Auto focus zoom lens with IR cut filter Zoom Ratio: 10x optical zoom plus 16x digital zoom Color: full color or black and white mode Day & Night image modes: Automatic or scheduled transition between modes Minimum illumination: Color: 0.7 lux@F1.8 B/W: 0.02 lux@F1.8 View: -Wide Angle: - Horizontal: 51.3 degree - Vertical: 39.3 degree -Max. Zoom Angle: - Horizontal: 5.6 degree - Vertical: 7.3 degree
Audio	Built-in omni-directional microphone Sensitivity: -40dB +/- 3dB (5 meters max.) Frequency: 100~20000Hz S/N: >60dB Codec: ARM/PCM
Pan & Tilt	Pan: -165° ~ +165° Tilt: up 84° and down 31° Preset positions: 20 Auto Patrol and manual controls
Image & Video	Compression: simultaneous H.264 / MPEG-4 / MJPEG Profiles: up to 4 profiles simultaneously IRIS Control /white balance control: automatic Resolution: 704 x 480, 352 x 240, and 176 x 112 @ 30fps (NTSC) Resolution: 704 x 576, 352 x 288, and 176 x 144 @ 25fps (PAL) Built-in ICR

TV-IP612P/WN (Wireless N) Pan/Tilt/Zoom Internet Camera

GPIO	Input: 1 set Output: 1 set
Micro SD slot	Micro Secure Digital card (up to 16G)
Hardware	
Network	IEEE 802.3u 10/100Mbps Auto-MDIX Fast Ethernet
LED	Power, Link/Act
Reset Button	Reset to factory default
Power Consumption	12 Watts (max.)
Power	12V, 2A external power adapter
Dimension	125 x 130 x 125 mm (4.9 x 5.1 x 4.9 in.)
Weight	Camera: 800 g (28.22 oz.)
Temperature	Operating: 0°C ~ 45°C (32°F ~ 113°F) Storage: -15°C ~ 60°C (5°F ~ 140°F)
Humidity	Max. 90% (non-condensing)
Certifications	CE, FCC
Requirement	
To View Camera	Internet Explorer 7.0 or above, Firefox 3.5 or above, Safari 4.0 or above
To Run Software	Windows 7 (32/64-bit), Vista (32/64-bit), XP (32/64-bit)
IPView Pro 2.0	Channel: supports up to 32 cameras Record/Playback/Motion Detection/Audio
Network Protocols	IPv4, ARP, TCP, UDP, ICMP DHCP Client, NTP Client, DNS Client, DDNS Client, SMTP Client, FTP Client HTTP Samba Client PPPoE UPnP RTP (Real Time Protocol) RTCP (Real Time Control Protocol) RTSP (Real Time Streaming Protocol)
Wireless (TV-IP612WN only)	
Standard	IEEE 802.11b, IEEE 802.11g, and IEEE 802.11n
Frequency	2.4 ~ 2.497 GHz ISM band

Modulation	DQPSK, DBPSK, DSSS and CCK OFDM: BPSK, QPSK, 16QAM, 64QAM
Antenna	2 x detachable 2dBi dipole antennas (Reverse-SMA connector)
Date Rate	802.11b: up to 11Mbps 802.11g: up to 54Mbps 802.11n: up to 300Mbps
Security	64/128-bit WEP, WPA/WPA2-PSK
Output Power	802.11b: 18dBm (typical) 802.11g: 15dBm (typical) 802.11n: 13dBm ((typical)
Receiving Sensitivity	802.11b: -85dBm at 11Mbps 802.11g: -73dBm at 54Mbps 802.11n: -65dBm at 300Mbps
Channels	1~11 (FCC), 1~13(ETSI)
Management	
Accounts	Up to 20 user accounts
Remote Login	Remote management supported
Backup / Restore	Save/retrieve configuration files
Log	System log up to 1023 entries
Settings	
Image	Brightness, contrast, saturation, sharpness, white balance, flip, mirror (horizontal/vertical), black & white, day, night, schedule mode
Video Setting	Encoding Type: MJPEG / MPEG-4 /H.264 - Resolution: 704 x 480, 352 x 240, 176 x112 (NTSC) - Resolution: 704 x 576, 352 x 288, 176 x144 (PAL) - Max. frame rate: 30 fps (NTSC) / 25fps (PAL)
Recording	Resolution: Define individual resolution for up to 4 profiles Required storage: 32MB (minimum per profile) Recording type: event based (motion detection and digital input trigger), continuous, and scheduled
Snapshot	Trigger event: motion detection or digital input signal Action: send alert email and/or upload to FTP Real time snapshot
Port Settings	HTTP port: 80 (default) RTSP port: 554 (default)

Dynamic DNS	Yes
Time	Synchronize with NTP server or set time / date manually

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

TV-IP612P / TV-IP612WN – 3 Years Warranty

Camera's motor, AC/DC Power Adapter, Cooling Fan, and Power Supply carry 1 year warranty.

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.

WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code. These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license.

PWP05202009v2



TRENDnet[®]

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>