

Changing the Adapter Ring

1. Unfasten the zipper and pull back the fabric around the BoomBox adapter ring.
2. Use a Philips screwdriver to remove the screws and washers, then remove the thumbscrew and washer.
3. Remove the adapter ring from the BoomBox.
4. Insert the replacement adapter ring.
5. Replace the washers and screws. Make sure to insert the thumbscrew in the recessed hole. Tighten until secure.

AVAILABLE ADAPTER RINGS

MODEL #	MOUNT TYPE
BBAR-BRL-144	BRONCOLOR
BBAR-EL-144	ELINCHROM
BBAR-PRO-144	PROFOTO
BBAR-BOW-144	BOWENS



One-Year Limited Warranty

This Angler product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Angler Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Angler along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.anglerlights.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.
www.gradusgroup.com

Angler is a registered trademark of the Gradus Group.
© 2022 Gradus Group LLC. All Rights Reserved.

