



CROSSFADE 3 WIRELESS XFBT3

OVER-EAR BLUETOOTH® HEADPHONES

USER MANUAL

CAUTION

If serial number on the product, the manual cover or bottom of packaging is missing or defaced, please return to retailer immediately.

READ ME

Before using this product, carefully read the safety and warranty information in the booklets provided. Please then keep the documents where they can be available for immediate reference. To acquire a full printable version of the manual, please visit www.v-moda.com/manuals



Qualcomm®
aptX™ HD




IMPORTANT NOTES

- * This document explains the specifications of the product at the time that the document was issued. For the latest information, refer to www.v-moda.com.
- * Use a standard USB AC adaptor (5V /over 500mA) for charging.
- * This product is equipped with a lithium-ion battery.
- * Even if you do not use this product for an extended period of time, you should charge it once every three months to prevent the internal lithiumion battery from degrading.
- * Ambient temperature range during charging: 5–35°C
- * However, in order to take full advantage of the rechargeable lithium-ion battery's performance, we recommend that you charge it in a temperature range of 10–30°C.
- * Take care not to pinch your fingers when opening or closing the headphones.
- * Charge the device using the included USB cable. Do not use the included USB cable with any other device.

WELCOME

Welcome to V-MODA, the music lifestyle. We sincerely hope you enjoy our headphones, the pinnacle of sound and quality design. With the essence of music at the foundation of all we do, we have precisely engineered our headphones to provide an enjoyable and natural sound signature, which invokes the sense of listening to your music live.

PACKAGE CONTENTS




1. Crossfade 3 Wireless Over-Ear Headphones
2. Carrying Case
3. 1-Button SpeakEasy Mic Cable
4. USB-C Charging Cable
5. 1/4" Pro Adapter


Headphones Accessories

BoomPro X Mic, custom metal shields, Audio Cables, 3-Button SpeakEasy Mic Cable and XL cushions are available at www.v-moda.com.

USING YOUR HEADPHONES




- 1 Very important: Place earcups on corresponding ear. "L" on left ear, "R" on right ear





- 2 Push hair back, extend the earcups from headband until they fit comfortably on ear, creating a snug fit to ensure highest sound quality and comfort



- 3** When wearing headphones wired (with cable connected), hang cable in front of your head to ensure headphones stay put during strenuous activity



- 4** When using the included cable, insert straight plug into earcup (not 45° angled plug)



- ① Volume Down
- ② Volume Up
- ③ 3-Way Switch / LED Indicator
- ④ Multifunction
- ⑤ Microphone
- ⑥ 3.5mm Stereo Mini Port
- ⑦ Charge Port

STEP BY STEP GUIDE

1 ON/OFF

To turn headphones on, slide the 3-way switch to the middle position. LED will start to blink once per second

2 PAIRING NEW DEVICES

Once powered on, slide 3-way switch to the right, hold 3 seconds, when the LED starts to blink twice per second, release the switch. The switch will return to the middle position and begin to search. Once **“V-MODA Crossfade 3”** appears in the “new Bluetooth devices” section on your phone, select it to begin pairing

3 CONNECTING PAIRED DEVICES

Once powered on (3-way switch in middle position) the headphones automatically connect to last paired device in a few seconds. Be sure the Bluetooth on your device is on

4 CHARGING

Connect the USB-C charging cable to charge headphones

To prevent malfunction or equipment failure, turn the volume down and turn the headphone off before connecting to a power source

Low Battery

Blinking orange LED

Charging

Fading orange LED

Fully Charged

White LED

5 PAIRING A SECOND DEVICE

a. Ensure the headphones are switched off, charged and within 1m of the device

b. Activate Bluetooth in the settings of your new device

c. Once powered on, slide switch to the right, hold 3 seconds, when the LED starts to blink twice per second, release the switch and enter secondary pairing mode (sonar sound)

d. When **“V-MODA Crossfade 3”** appears in the “new Bluetooth devices” section on your device, select it to pair

Note: The headphones' memory can hold up to 8 devices. You will only need to re-pair a device if the headphones is reset or if you pair a ninth device. Pairing a ninth device will overwrite the first device paired.

6 MULTIPOINT

- a. Ensure that the first pairing and secondary pairing procedures have been completed
- b. To switch between devices via multipoint, ensure that both of your paired devices have Bluetooth activated
- c. Turn the headphones off and then on again
- d. Select **"V-MODA Crossfade 3"** in the Bluetooth settings of the device you want to play audio from
- e. Press "Play" to play audio from your selected device
- f. The headphones will now switch its active connection to your selected device. You may only listen to audio from one device at a time

7 MULTIFUNCTION BUTTON

	Answer a call	Press once (music pauses automatically)
	Refuse incoming call	Press and hold for 1-2 seconds then release
	Play and pause audio	Press once
	Skip to next song	Press twice
	Go to previous track	Press three times
	Summon voice assistant	Press and hold for 3 seconds*

*Depending on your devices, there may be restrictions on the use of the voice assistant.

8 VOLUME BUTTONS



Volume Up

Press + button



Volume Down

Press – button



Reset paired device history

Press and hold "+" and "-" at the same time for 3 seconds. LED lighting will change to blinking white

WIRED MODE

1 DURING MUSIC PLAYBACK

- Click V button once to pause and again to resume playback
- Click V button twice quickly for next track
- Click V button three times quickly for previous track

2 DURING CALLS

- Click V button once to answer incoming call, click once to end call
- Press and hold V button down for about two seconds to decline an incoming call



Compatible with all Bluetooth smartphones, tablets, iPhone®, iPad®, iPod®, Android™, computers and any gaming or audio device with a 3.5mm or 6.35mm (1/4") port.

GETTING STARTED WITH THE APP

1 Get the **“V-MODA HEADPHONE EDITOR”** app from Google Play or the App Store and download/install the app to your device

2 Pair the headphones with your device settings

Go to **STEP BY STEP GUIDE 2 PAIRING NEW DEVICES** and follow the procedure

*If you're using an already-paired mobile device:

Go to **STEP BY STEP GUIDE 3 CONNECTING PAIRED DEVICES** and follow the procedure

3 Open and activate **“V-MODA HEADPHONE EDITOR”** app

If you see **“V-MODA Crossfade 3”** on the screen, select it to connect. Tap "pairing" if the app screen asked you for pairing. When the update software is available, you will receive a notification to update the software.

If the headphones update cannot be completed, please note the following and update again

- Fully charge the headphones and your device
- Move the device closer to the headphones
- Move away from any possible interference (wireless routers, other Bluetooth devices, microwaves etc.)
- Close any application on your device that is not in use and disable Wi-Fi

In case, you cannot connect

After closing the app and disconnect Bluetooth, try the following procedures:

- a. Delete V-MODA Crossfade 3 from Bluetooth device list of your device
- b. Clear headphones' device paired history by following **STEP BY STEP GUIDE 8 RESET PAIRED DEVICES HISTORY**
- c. Retry the pairing by following the pairing procedure
- d. Even after trying this procedure if you are not able to connect, reboot your device and try pairing procedure again

FOLDING YOUR HEADPHONES

- 1 Hold the two ear cups lightly together, cushion to cushion
- 2 Place the heel of other hand on top of headband
- 3 Push gently together to activate the CliqFold hinge
- 4 Place the headphones in the carrying case, with the headband placed closest to the case's hinge
- 5 Insert any cables you wish in the extra space below
- 6 Zip the carrying case to close



TROUBLESHOOTING

If you are experiencing trouble with your headphones, please refer to the troubleshooting guidelines below. If the problem persists, please contact the V-MODA Support Team or the nearest Roland service center.

TROUBLE	SUGGESTIONS
Pairing process trouble	• Make sure headphones are not connected to the charger and they are powered on • Turn off the headphones and turn them on again • Remember to turn on the Bluetooth feature on your device • Turn off the Bluetooth feature on any other device which has been previously paired • Reset paired devices history by pressing and holding Volume + and Volume - for 3 seconds • Try to pair with another device to make sure that both the headphones and your Bluetooth device are working properly • Go to Bluetooth settings and select “V-MODA Crossfade 3”

TROUBLE

SUGGESTIONS

Receiving no audio or low quality audio from an audio source

- Check the battery
 - Check the pairing
 - Make sure the audio source is playing
 - Make sure the volume on the device is not muted or turned down
 - Reboot the source/device
 - Turn off the headphones and turn them on again
 - Reset paired devices history of the headphones
 - Try streaming from another device or select another track
 - Move the device and headphones closer (max 33 feet or 10m)
 - Keep away from any possible interference (wireless routers, other Bluetooth devices, microwaves etc.)
 - Close any applications on your device that are not in use and disable Wi-Fi
-

TROUBLE	SUGGESTIONS
Audio and video do not match	Try streaming from another device or select another track. Due to technology limitations, there may be a delay from some sources or applications
No audio (in wired mode)	Make sure the audio device and the headphones jacks are free of debris and that the cable is securely connected
Lack of or excessive bass or treble (in wired mode)	Turn off any audio enhancement features on audio device. Make sure cable is firmly connected to the headphones (use straight plug) and device (use 45° plug). If the problem persists, try another cable
Uneven sound (in wired mode)	Make sure cable is firmly connected to the headphone by ensuring male 3.5mm is inserted into female 3.5mm all the way

TROUBLE

SUGGESTIONS

Distorted sound

Check to make sure the problem is not with the audio device or the file you are listening to. Ensure the EQ settings on the device are set properly. Make sure you have a snug fit and that the driver is pointing directly towards the ear

Headphones will not charge

- Make sure the charging cable and source are functioning properly
 - Make sure both USB plugs are firmly connected into their sockets
 - Disconnect and reconnect the USB charging cable
 - If charging with your computer, make sure the USB port is powered and remember to plug in your computer
-

TROUBLE

SUGGESTIONS

Rapidly blinking orange LED

A charging error occurred

Could the ambient temperature be above 35°C (95°F)?

- Charging might stop for a while in order to protect the rechargeable lithium-ion battery. Use the unit in the recommended ambient temperature range of 10–30°C (50–86 °F)
 - If the indicator continues blinking fast orange even though you are charging in the recommended temperature range, contact the V-MODA Support Team or your dealer or nearest Roland service center
-

Headphones are not responding

Charge the headphones and then turn on

©2022 V-MODA. All rights reserved.

V, V-MODA and the V-MODA logo are registered trademarks of V-MODA.

Patents: roland.cm/patents

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.
and any use of such marks by V-MODA is under license.

Qualcomm aptX is a product of Qualcomm Technologies, Inc. and/or its subsidiaries.
Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries.
aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and
other countries.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

Google Play and the Google Play logo are trademarks of Google LLC.

Other trademarks and trade names are those of their respective owners.

Roland Corporation U.S.
5100 S. Eastern Ave, Los Angeles, CA90040-2938

ISSUES WITH THE PRODUCT

For any issues relating to your V-MODA product,
please contact our Support Team directly.

VISIT

www.v-moda.com/support

EMAIL

support@v-moda.com

CALL

+1 888.866.3252



REGISTER NOW AT
www.v-moda.com/register

