




Oben®

TT-LAC

Lateral Adapter for
Tabletop Tripods



You're on steady ground®

Thank you for choosing Oben

The Oben TT-LAC lateral adapter adds more camera placement options to your tabletop tripod setup.

Ideal for vlogging and podcasts, this adapter will add the option of shooting straight down to capture product shots, artwork, and documents.

The lateral arm adjusts from 6.5 to 12.7 inches, and the 6.6-pound load capacity will hold smartphones, web cams, action cameras, and point-and-shoot cameras.

The TT-LAC is compatible with Oben's extensive lineup of tabletop tripods.

**Warnings:**


- *Please read and follow these instructions, and keep this manual in a safe place.*
- *Keep this unit away from water and any flammable gases or liquids.*
- *Clean the unit with only a soft, dry cloth.*
- *Make sure that this product is intact and that there are no missing parts.*
- *Do not exceed the maximum load capacity.*
- *Always use a counterweight for tripod stability.*
- *All images are for illustrative purposes only.*

Visit our website at **ObenSupports.com**
for more Oben products.


OPERATION

1. Screw the head onto the tripod.

If the tripod has a 3/8-16 mounting screw, remove the reducer bushing from the head's socket.




2. Unscrew the counterweight hook.




3. Slide the arm into the collar, and tighten the collar lock until secure.


Loosen the collar to adjust the length or find a balance point for your attached device.



4. Screw the counterweight hook back onto the arm.




5. Loosen the twist locks to adjust the arm's length, and retighten until secure.




6. Loosen the pan lock, and adjust the adapter's direction. Retighten until secure.

The pan lock and the locking collar are ratchet handles. If the tripod or attached device prevents the handles from turning, pull them out and reposition them. Release them, and the handles will reengage.




7. Attach an adapter to the mounting screw for a smartphone, or screw a web cam, point-and-shoot camera, or action camera directly onto the 1/4-20 mounting screw.



8. Attach a counterweight to stabilize the arm.

Important: Always use a counterweight for tripod stability and for the safety of your gear. When panning or adjusting the length, always support your attached device with one hand.



SPECIFICATIONS

Mounting Socket	3/8-16 female thread 1/4-20 female thread (with included reducer bushing)
Load Capacity	6.6 lb. (3 kg)
Arm Length Adjustment	6.5 to 12.7 in. (16.5 to 32.25 cm)
Sections	3
Adjustments	Length, pan
Material	Carbon fiber and aluminum
Weight	4 oz. (113 g)

Five-Year Limited Warranty

This Oben product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of five (5) years from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function. This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state. To obtain warranty coverage, contact the Oben Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Oben along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.obensupports.com or call Customer Service at 212-594-2353.



Product warranty provided by the Gradus Group.
www.gradusgroup.com



www.obensupports.com

Oben is a registered trademark of the Gradus Group.
© 2024 Gradus Group LLC. All Rights Reserved.