

ML-LSR

LightSeeker Remote

FOR POWERHOUSE, PORTABRIGHT,
AND ENDEAVOR MONOLIGHTS

USER MANUAL



G genaray®

INTRODUCTION

THANK YOU FOR CHOOSING GENARAY

The Genaray ML-LSR LightSeeker Remote is a dedicated remote for Genaray's Powerhouse, PortaBright, and Endeavor LED monolights as well as select Genaray lights that support the LightSeeker remote system. The 16-channel remote controls dimming on all models from 0% to 100% in 10% increments, and color temperature on bi-color models from 3200 to 6500 K in 100 K increments. The 2.4 GHz radio signal is effective at controlling your lights from over 100 feet away without line of sight.

PRECAUTIONS



- Please read and follow these instructions, and keep this manual in a safe place.
- Keep this unit away from water and any flammable gases or liquids.
- Do not attempt to disassemble or repair this product. Doing so will void the warranty, and Genaray will not be responsible for any damage.
- Install the batteries in the proper orientation. Installing batteries in the reverse orientation can cause them to leak, overheat, or explode.
- Remove the battery when storing the remote.
- Keep this product away from children.
- Images are for illustrative purposes only.

PRODUCT OVERVIEW



POWERING ON THE REMOTE

1. Remove the battery cover and install two AA batteries. Make sure they're in the proper orientation. Then replace the battery cover.
2. Press and hold the on/off button until the screen illuminates.

Note: After 5 minutes of inactivity, the remote will switch to standby mode to preserve battery life. To wake up the remote, press any button to display the control screen.

CHANNEL SELECTION

Press the channel select button to highlight the current channel setting. Use the up/down buttons to set the channel.

Important! Make sure the Genaray lights are set to the same channel as the remote. Refer to the user manuals that came with the lights to select their channels and groups.

ADJUSTING THE SETTINGS

Color Temperature

1. Press the group's color temperature button to highlight the current setting.

To access group E, press and hold the group D power button until group E appears on the display. Press and hold the group E power button to return to group D.

2. Use the up/down buttons to change the color temperature from 3200 to 6500 K in 100 K increments.

Brightness

1. Press the group's power button to highlight the current setting.

To access group E, press and hold the group D power button until group E appears on the display. Press and hold the group E power button to return to group D.

2. Use the up/down buttons to adjust the brightness from OFF to 100% in 10% increments.

POWERING OFF

Press and hold the power button until the LCD screen turns off.

If the lights are still on, they will remain at the last values that were set on the remote. The color temperatures and brightness settings can still be adjusted via their onboard controls.

SPECIFICATIONS

Channels: 16

Groups: 5

Functions Supported: Dimming, color temperature (bi-color LEDs)

Frequency: 2.4 GHz

Frequency Range: ≥ 100 ft. (30.5 m)

Power: AA Battery (x2)

Dimensions: 2.8 x 4.1 x 1.5 in. (7.1 x 10.5 x 3.8 cm)

Weight: 4.75 oz. (135 g) with batteries

ONE-YEAR LIMITED WARRANTY

This Genaray product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. Genaray's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at Genaray's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by Genaray. If the product has been discontinued, Genaray reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, GENARAY MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Genaray Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Genaray along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information, or to arrange service, visit www.genaray.com or contact us at info@genaray.com.