

USER MANUAL


Light receiving form: reflected light
Light receiving angle range:
Pro 7 degrees, Lite 30 degrees
Photosensitive element type:
high-precision silicon photodiode array
Metering mode:
Aperture priority, Shutter priority

Metering accuracy: ±0.1EV
ISO: 3~8000
Shutter: 1/8000~60s (in 1/3 steps)
Aperture: F1~F64 (in 1/3 steps)
Measurement mode: single light measurement, continuous light measurement, single light measurement and ranging, continuous light measurement and ranging

EV range: 1~22(in 1/3 steps)
Screen size: 0.96 inches
Battery specifications:
370mAh lithium-ion polymer battery
Charging parameters: Type-C DC5V±10%
Dimensions: 36*32*20 (excluding cold shoe mount)

IMPORTANT TIPS

Before shooting, please make sure that the **laser transmitter** is **turned off** to avoid the laser point being captured by the camera.



Switch on/off

Press the M key again to turn on the device, and it will automatically shut down after 1 minute of inactivity

Switch between "Aperture priority mode" and "Shutter priority mode"

Deep press the M key to switch between "Aperture priority mode" and "Shutter priority mode", and rotate the dial to adjust the corresponding parameters.

Single measurement:

Light press the M key.

Continuous measurement:

Light press the M key for 8 seconds until the **C** icon displayed on the screen.

Mode Switching

Turn the "Laser ON/OFF" button on the side of the body to switch between "Light and ranging mode" and "Single light mode".

How to adjust ISO value

Deep press the M key for 2 seconds until the **ISO** icon flashes on the screen, enter the "ISO adjustment mode". Rotate the dial to adjust the ISO parameters and press the M key to exit.

Laser ON:

Light and ranging mode

Laser OFF:

Light mode (disable ranging function)

Distance unit (m/ft) switch

Deep press the M key for 5 seconds until the **Distance unit** icon on the screen flashes, enter the "Distance unit switching mode", turn the adjustment dial to adjust the distance unit, and press the M key to exit.

Product Warranty Policy

We provide quality assurance policies in different countries and regions that strictly abide by local laws and regulations. For details, please consult the dealer.